

Handleiding (NL)

Oplaadstation geschikt voor Switch 2 controllers

Introductie

Het GNWare oplaadstation (SN006) is geschikt voor de tweede generatie Nintendo Switch-controllers. Met dit station kunt u gelijktijdig vier controllers opladen.

Gebruiksaanwijzing

1. Aansluiten

1. Sluit de meegeleverde USB-kabel aan op een geschikte 5 V / 1 A oplader.
2. De vier indicatorlampjes lichten afwisselend blauw en groen op en schakelen daarna over naar stand-by.
3. Wanneer er nog geen controller is geplaatst, blijven de lampjes uit.

2. Plaatsing van de controllers

1. Plaats de linker- en rechtercontrollers in de daarvoor bestemde houders.
 - De “-” controller gaat in een van de twee linkerposities.
 - De “+” controller gaat in een van de twee rechterposities.
2. Als een controller verkeerd wordt geplaatst, blijft het lampje uit en wordt er niet opgeladen.

3. Opladen

- Blauw lampje: batterij wordt opgeladen.
- Groen lampje: batterij volledig opgeladen.

4. Verwijderen

1. Haal de controller uit het laadstation zodra deze volledig is opgeladen. Het lampje gaat direct uit.
2. Verwijder de meegeleverde USB-kabel uit de aangesloten oplader of USB-poort.

Let op

- De aangesloten (wand)adapter of het stroomuitgiftepunt mag maximaal 5 V / 1 A leveren.
- Gebruik geen adapters met hogere stroomsterkte dan aangegeven, dit kan de oplader of controllers beschadigen.

Veiligheidsinformatie

- Gebruik het apparaat alleen met Nintendo Switch 2-controllers.
- Plaats de oplader op een droge, vlakke ondergrond, uit de buurt van water, warmtebronnen of direct zonlicht.
- Steek geen metalen voorwerpen in de laadpoorten.
- Bij oververhitting, vreemde geuren of rook: koppel de oplader direct los van het stroomnet.
- Niet demonteren of zelf repareren; reparaties mogen alleen door gekwalificeerd personeel worden uitgevoerd.
- Verwijder altijd de stroom van het oplaadstation zodra het laden is voltooid.
- Niet geschikt voor kinderen onder de 16 jaar.

Importeur

George Napoli
Alexander Fleminglaan 4
6721BA BENNEKOM
Nederland
info@georgenapoli.nl

Model: SN006

Made in China



User manual (EN)

Charging station suitable for Switch 2 controllers

Introduction

The GNWare Charging Station (SN006) is designed for second-generation Nintendo Switch controllers. With this station, you can charge up to four controllers simultaneously.

Instructions for Use

1. Connecting

1. Connect the included USB cable to a suitable 5 V / 1 A charger.
2. The four indicator lights will flash alternately blue and green, then switch to standby mode.
3. When no controller is placed, the lights will remain off.

2. Placing the Controllers

Place the left and right controllers in the designated holders.

- The “-” controller goes into one of the two left positions.
- The “+” controller goes into one of the two right positions.

If a controller is placed incorrectly, the light will remain off and the controller will not charge.

3. Charging

- Blue light: battery is charging.
- Green light: battery is fully charged.

4. Removing

1. Remove the controller from the charging station once it is fully charged. The light will turn off immediately.
2. Disconnect the included USB cable from the charger or USB port.

Note

The connected (wall) adapter or power source must provide a maximum of 5 V / 1 A.

Do not use adapters with higher current than specified, as this may damage the charger or controllers.

Safety Information

- Use the device only with Nintendo Switch 2 controllers.
- Place the charger on a dry, flat surface, away from water, heat sources, or direct sunlight.
- Do not insert metal objects into the charging ports.
- In case of overheating, unusual odors, or smoke, disconnect the charger immediately from the power source.
- Do not disassemble or attempt repairs; repairs should only be performed by qualified personnel.
- Always disconnect the charger from the power source once charging is complete.
- Not suitable for children under 16 years old.

Importer

George Napoli
Alexander Fleminglaan 4
6721BA BENNEKOM
Nederland
info@georgenapoli.nl

Model: SN006

Made in China

