


# PRODUCT INSTRUCTIONS

AIR HEATER




XH-1201

## product instruction

This product uses a heating body with high thermal efficiency and strong stability, and is designed with a rapid thermal air supply system, built-in induction thermostat and dump switch, with beautiful appearance, stable performance, fast heating, even heat dissipation, Long service life, good insulation, high temperature resistance and other characteristics, human safety performance is high, suitable for home, office and other places

## structure introduction



## Instructions

1. Open the package and take out the blower. Put the blower on a smooth surface(it is forbidden to use this machine on soft and unstable surface such as carpet and bed).
2. Please ensure that the power supply and socket meet the parameter requirements of the machine nameplate.
3. Please make sure that the heater switch is at the position of "0" before use
4. Press the temperature gear switch and adjustment: "0" is the power off key,"I" is the warm air gear, and "II" is the hot air gear

## safe caution

- The blower must not be placed under a power outlet. A reliable power outlet must be used, the capacity of outlet, plug and power lead should be above 10A.
- Do not point the air supply direction towards the socket, plug and power cord to avoid accidents.
- The product is strictly prohibited to be used in the environment of inflammable and explosive articles. It is strictly prohibited to use in the environment with severe dust and oil pollution. The surrounding air should be ventilation when used. The ambient temperature should not exceed 30 degree. Unplug the power when there is no one in the room.
- Do not use this heater near the bathtub, shower head or swimming pool.
- Do not put anything on the machine, do not cover the heater, do not barbecue on the heater, so as to avoid fire
- if the product breaks down, please contact the dealer or manufacturer for repair. Do not dismantle the machine for repair without authorization

- Do not insert foreign bodies into the inlet and outlet to avoid danger . Please pay special attention to children.
- It is strictly forbidden to touch the protection net cover when the heater is working to prevent hot scald . Please pay special attention to children
- The heater shall not be used with a program , timer or any other device with an automatic power supply.

**Warning : In order to avoid overheating, it is forbidden to cover the heater and block the air inlet and outlet of the heater with foreign matters!**

## Cleaning and Maintenance

- Before maintenance , please unplug the power cord , and only after the heater cools down
- Wipe with soft cloth when surface area dust ; When the surface is too dirty , use water below 50 degrees Celsius with a soft cloth to wipe and dry.
- Do not use gasoline , thinner , or any detergent that can damage the surface , or put the whole machine in water.
- After cleaning , it can be used only after the organism is fully dried.
- During storage , the heater should be cooled , dried and packed in a dry and ventilated place.

## Product technology

name : air heater  
item No . XH-1201  
rate frequency : 50HZ

product serial : personal exclusive  
Rate power : 1200W

## Warranty card

For your benefit, please keep [ product Warranty card ] properly for warranty purposes

The product name		Product Model	
Buy address		Purchase date	
contact phone number		Invoice no	
Address of the user			
The cause of the problem			

**Thank you for buying this product , in order to better provide high-quality after-sales service , please give the following cooperation**

1. When purchasing, please ask the seller to issue the sales proof as the warranty basis.
2. Please fill in the card in detail and stamp the distributor's seal on the card to take effect.
3. Please read the terms of the maintenance regulations in detail.
4. If you need any service, please contact the local dealer directly or call the customer service hotline.

### **Maintenance regulation**

1. When in the warranty period, the whole machine shall be guaranteed for six months under normal use (from the date of purchase, subject to the invoice date).
2. During the warranty period, under any of the following circumstance, the material cost or service fee will be charged as appropriate. Please understand!
  - a. Damage caused by improper use, maintenance
  - b. damage caused by disassembly
  - c. The absent of the vouchers or valid invoice.
  - d. The model does not match the model of the repaired product.
  - e. The appearance is naturally stained due to use.
  - f. Damaged for commercial use.
  - g. Damage caused by force majeure shall not be included in the warranty.
3. This card cannot be reissued. Please keep it properly.
4. For products beyond the scope of maintenance and beyond the warranty period, only the cost of parts and materials and round-trip freight shall be properly charged.