


INSTRUCTION MANUAL



Kiki P 50/70 Clear Shade
104320 / 104321 / 104322 / 104323

| | | |
|-----------------------------|-----------|-----------|
| <p>1.</p> | <p>2.</p> | |
| <p>3.</p> | <p>4.</p> | |
| <p>5.</p> | <p>6.</p> | <p>7.</p> |
| <p>Overall Size:</p> | | |