


Phone Holder User manual

Welcome

This Phone Holder suits for Mi Electric Scooter, Ninebot KickScooter, and other short-distance transportation with handlebar diameter of 18~36 mm. It is suitable for most phones with screen size ranging from 4.7 to 6.5 inches.



Diagram

Holder clamping device



Telescopic arm

Adjustment nut



Assembly Instruction

Ball shaft buckle





Thick anti-slip rubber pad


Thin anti-slip rubber pad

Buckle


Hand screw

Installation


Unscrew adjustment nut and place it on ball shaft, and connect the ball shaft buckle with the tail of holder clamping device.



Attach the phone holder to the handlebar and adjust it to the proper position.



Rotate hand screw to the slot of buckle and tighten hand screw, adjust the phone holder to the appropriate angle, and tighten adjustment nut.



Precautions

1. You need to turn off the scooter first before installing the phone holder.

- 2.Both thick anti-slip rubber pad and thin anti-slip rubber pad are to be installed on the Mi Electric Scooter while only thin anti-slip rubber pad is required on Ninebot Kickscooter.
- 3.Do not use your mobile phone when riding an electric scooter or other short-distance transportation.

Specifications

Product	Phone Holder
Brand	Ninebot
Model	SR-168
Size	140 × 70 × 98 mm
Weight	101 g
Material	ABS & TPU & PP
Color	Black

5 After-sale Service

This is the manufacturers limited warranty ("Limited Warranty") for the Phone Holder ("Product") for consumers in Europe, Asia, the Americas and Africa ("Territory"). This Limited Warranty describes the service available to you in the event your Product requires warranty service, and you may have additional protections under your local laws.

This Limited Warranty is an additional warranty, that does not in any way affect or limit the statutory rights you may have as a consumer, for example with respect to conformity. This sheet and the original

purchase receipt for the purchase of your Product are the documents defining the Limited Warranty. Please retain this document and the original purchase receipt to preserve your warranty service.

- 1. Within 14 days of purchasing, the customer can return the product without any reason but the customer needs to bare the return costs.
- 2. If the product displays the functional error, the customer can do as below.

Service type	Service policy
i Refurn	Within 14 days of purchasing, starting from the next day of the signature, the product can be returned with quality issues.
Exchange	Within 14 days of purchasing, starting from the next day of the signature, the product can be exchanged with quality issues.

Product error list

Functional error	
Phone Holder	New products with broken or defects

Friendly reminder: packaging box is used to ensure the product condition during transportation, please keep the packaging box for 14 days since the date of purchase.

Not covered

- 1. Repaired by unauthorized retailer, misuse, bump, neglect, abuse, leakage, accident, alteration and incorrect use of the product and its accessories, or tear, alteration the security tag.
- 2. Exceed the warranty period.
- 3. Force majeure damage.
- 4. Not comply with the functional error listed in the table above.
- 5. Damages caused by man-made reason.