

THOR - MJOLNIR

User manual

KEYS

(1) Left front key, (2) Right front key, (3) Scroll wheel/middle key, (4) Backward key, (5) Forward key, (6) *Mode switch, (7) DPI change, (8) CTRL+C, (9) CTRL+V, (10) WIN+D, (11) ALT+F4

*The Mode switch (6) has three functions/circularly

• Mode 1

Press the Mode switch (6) until the mouse shows a red color:

You are in the default position. The keys will have the functions you see on the image.

• Mode 2

Press the Mode switch (6) until the mouse shows a blue color:

The left front key (1), right front key (2), scroll wheel (3) and the DPI changer (7) will work as normal.

The forward key (5), backward key (4), CTRL+C key (8), CTRL+V key (9), WIN+D key (10) and the ALT+F4 key (11) will not have any function in this position.

• Mode 3

Press Mode switch (6) until the mouse shows a blue color:

The left front key (1), right front key (2), scroll wheel (3), backward key (4), forward key (5) and DPI changer (7) will work as normal.

The CTRL+C (8), CTR+V (9), WIN+D (10) and ALT+F4 (11) will not have any function in this position.



11 RGB LIGHTING EFFECTS

Toggle through the RGB lighting effects by pressing the Scroll wheel/middle key (3) + right front key (2) at the same time.

1. Sleep mode

Only one light-zone will show a dimmed red color

2. Constant mode

All-light zones will light up - fixed rainbow color pattern

3. Blinking mode

All light-zones will light up - fixed blinking rainbow color pattern

4. Breathing mode

All light-zones will gradually fade in/out in a rainbow color pattern

5. Neon mode

All light-zones will slowly change colors

6. Running RGB wave mode

All light-zones will toggle/wave through all colors

7. Move mode

Individual light-zones will be activated when you move the mouse

8. Rolling mode

Rolling light-zones effect - colors change fast

9. Flicker mode

All light-zones will show random colors fast

10. Yoyo mode (slow)

All light-zones will be activated in a slow yoyo pattern

11. Yoyo mode (fast)

All light-zones will be activated in a fast yoyo pattern



DPI ADJUSTMENT

When clicking the DPI key (7), the DPI settings will change and your mouse will either get faster or slower, depending on the setting you choose.

Each click on the DPI key (7) will make your mouse blink shortly with a color indicating the current DPI setting.

RED = 500 DPI	BLUE = 1,000 DPI
GREEN = 2,000 DPI	ORANGE = 4,000 DPI
PURPLE = 8,000 DPI	CYAN = 12,000 DPI (Interpolated)

HARDWARE SPECIFICATIONS

Sensor :	Pixart 3360
Keys :	11
Polling Rate :	1000HZ
IPS :	250
Acceleration :	50G
Connection :	USB (Plug & play)
Software:	Software for download (mouse is fully programmable)
Mouse type:	Ambidextrous (for right & left hand users)
DPI :	6 levels – adjustable from 500 to 12,000 DPI
Switches :	Omron (20 million clicks)
RGB Light :	7-zone true RGB (16.8 million colors)
Color modes :	11

SOFTWARE FOR DOWNLOAD

The MJOLNIR mouse is fully programmable.

You can customize:

- The RGB light settings
- DPI settings
- Macros functions
- Key functions
- User profiles

...and a lot of other functions.

Please go ahead and download the MJOLNIR software & manual from:

www.1337-gaming.com/downloads

