

Height Adjustment Settings


Loosen the knob on the back of the Level Cup XL to adjust the overall height.



Rubber Cap Placement (Optional)

Follow these steps if your cup/bottle tapers towards the bottom, or if your drink feels somewhat loose in the Level Cup XL. *Important*: Adhesive solution may be extremely watery. Use caution while handling. Use of gloves and paper towels recommended.

- Cut tip of tube to expose adhesive.
- Apply only a couple drops of adhesive into the cap.
- While holding the Level Cup XL upside down, position the cap over the fin of the Level Cup XL. Repeat for remaining rubber caps. Glue dries immediately.



RPR-INS-417

This document, including images, may not be reproduced partly or fully without the expressed written consent of National Products, Inc.




1.800.497.7479 support@rammount.com rammount.com

Level Cup™ XL

Height Adjustment Settings


Loosen the knob on the back of the Level Cup XL to adjust the overall height.



Rubber Cap Placement (Optional)

Follow these steps if your cup/bottle tapers towards the bottom, or if your drink feels somewhat loose in the Level Cup XL. *Important*: Adhesive solution may be extremely watery. Use caution while handling. Use of gloves and paper towels recommended.

- Cut tip of tube to expose adhesive.
- 2 Apply only a couple drops of adhesive into the cap.
- While holding the Level Cup XL upside down, position the cap over the fin of the Level Cup XL. Repeat for remaining rubber caps. Glue dries immediately.





RPR-INS-417