




Manual

Wireless earbuds pro TZ-66

Introduction



1. Touch control button
2. LED indicator earbud
3. Eartip
4. Wingtip
5. Charging contact points
6. Type-C charging port
7. Wireless charging base
8. Charging case
9. Charging station earbud
10. LED indicator charging case

Connecting earbuds

Steps

1. Turn on Bluetooth on your device.
2. Pick up the earbuds from the charging case. The earbuds turn on, start pairing and search automatically for Bluetooth connection.
3. Connect the earbuds to your device via «Thunderz TZ-66» in the Bluetooth settings.


Note

When using the earbuds for the first time, remove the blue label from the bottom side of the earbuds.

Automatic connection:

After the earbuds are successfully connected to your device the first time: "Pick up the earbuds = automatic connection"
"Put earbuds in charging case = earbuds disconnect"

Touch control



Function	Control
Play/ Pause	1 x Touch L/R
Next/ Previous song	2 x Touch for next song L 2 x Touch for previous song R
Volume + / Volume -	3 seconds hold press volume +, L 3 seconds hold press volume -, R
Answer/ Hang up call	1 x Touch L/R
Reject call	2 seconds hold press L/R
Voice assistant activation	3 x Touch L/R
Turn on earbud	3 seconds hold press L/R
Turn off earbud	5 seconds hold press L/R

Tip:

Either earbud can be used individually. When doing so, the functions Volume +/- and Next/ Previous song will be disabled.

LED indicator

Charging case

Status	LED
Charging via Type-C cable	Red light flashes
Fully charged via Type-C cable	Red light on
The earbuds charge in the charging case	Blue light on (3 sec.), then off
Low battery	Red light flashes

Earbud

Status	LED
Charging	Red light on
Fully charged	Blue light on (5 seconds), then off
Low battery	Red light flashes
Search connection	Red and blue light flashing alternately
Connected	No light
Music/ calling	No light
Turn on	Red and blue light flashing for 2 seconds
Turn off	Red light flashes for 2 seconds

Specifications

Bluetooth version	V5.0 + EDR
Bluetooth range	10 meters/ 33 ft (unobstructed)
Dimensions earbud	25.2 x 23.3 x 21.9 mm
Dimensions charging case	71.1 x 40.0 x 27.2 mm
Weight earbud	4.5 gram/ 0.16 oz
Charging time earbuds	1 hr
Charging time charging case	1 hr (via Type-C)
Standby time	60 hrs
Battery capacity earbud	40 mAh
Battery capacity charging case	250 mAh
Input wireless charging base	DC 5V/ 1A

Package contents

- 1 x Wireless earbud pro L/R
- 1 x Charging case
- 2 x Eartips (S/M/L), 2 x Wingtip (S/M), 1 x Casual tip
- 1 x Type-C Charging cable
- 1 x Manual

Reset

When one or both earbuds will not connect to your device, reset the earbuds.

Steps

1. Remove «Thunderz TZ-66» from all Bluetooth devices it has been connected to, and turn off the Bluetooth on your device.
2. Turn off both earbuds and put them in the charging case.
3. Pick up the earbuds from the charging case and turn on the earbuds. Turn on Bluetooth on your device and connect «Thunderz TZ-66» to your device in the Bluetooth settings.
4. The Bluetooth connection of the earbuds has now been reset.

Note

Always reset the 2 earbuds at the same time.

Warnings



1. The earbuds cannot be submerged in water and do not withstand when used during shower or swimming.
2. Do not place the earbuds in direct sunlight or in hot/ moisture places.
3. Turn off the earbuds when not being used.
4. Do not try to disassemble the product.
5. Do not drop the earbuds or knock the earbuds to other surfaces.
6. If the volume of the earbuds is too long on high volume, it may lead to health problems. Be aware.

How to wear




1. Choose and place the eartip that best suit your ears.
2. Insert the earbud in the inner ear.
3. Turn the wingtip and find the most comfortable position.



Gebruiksaanwijzing

Wireless earbuds pro TZ-66

Introductie



1. Touch control button
2. LED indicator earbud
3. Eartip
4. Wingtip
5. Oplaadcontactpunten
6. Type-C oplaadpunt
7. Draadloze oplaadbasis
8. Oplaadcase
9. Oplaadstation earbud
10. LED indicator oplaadcase

Verbinding maken

Stappen

1. Zet Bluetooth aan op je apparaat.
2. Pak de earbuds uit de oplaadcase. De earbuds activeren, pairen en zoeken automatisch naar een Bluetooth verbinding.
3. Verbindt de earbuds met je apparaat via «Thunderz TZ-66» in de Bluetooth instellingen.

Note

Wanneer je de earbuds voor de eerste keer gebruikt, zorg dan dat je het blauwe stikkertje onderaan de earbuds verwijderd.

Automatisch verbinding maken:

Nadat je de earbuds de eerste keer met je apparaat hebt verbonden: "Earbuds uit de oplaadcase = automatisch verbonden"
"Earbuds terug in de oplaadcase = verbinding verbreken"

Touch bediening



Functie	Bediening
Play/ Pauze	1 x Tippen L/R
Volgend/ Vorig nummer	2 x Tippen volgend nummer L 2 x Tippen vorig nummer R
Volume + / Volume -	3 seconden ingedrukt houden volume +, L 3 seconden ingedrukt houden volume -, R
Oproep opnemen/ eindigen	1 x Tippen L/ R
Oproep weigeren	2 seconden ingedrukt houden L/R
Voice assistent activeren	3 x Tippen L/R
Aanzetten	3 seconden ingedrukt houden L/R
Uitzetten	5 seconden ingedrukt houden L/R

Tip:

Je kunt de earbuds ook afzonderlijk gebruiken. Hiermee vervallen wel de controls Volume +/- en Volgend/ vorig nummer.

LED indicator

Oplaadcase

Status	LED
Opladen via de Type-C kabel	Rood licht knippert
Volledig opgeladen via de Type-C kabel	Rood licht aan
De earbuds laden op in de oplaadcase	Blauw licht aan (3 sec.), daarna uit
Lage batterij	Rood licht knippert

Earbud

Status	LED
Opladen	Rood licht aan
Volledig opgeladen	Blauw licht aan (5 seconden), daarna uit
Lage batterij	Rood licht knippert
Verbinding maken	Rood en blauw licht knippert
Verbonden	Geen licht
Muziek/ bellen	Geen licht
Aanzetten	Rood en blauw licht knippert 2 seconden
Uitzetten	Rood licht knippert 2 seconden

Specificaties

Bluetooth versie	V5.0 + EDR
Bluetooth bereik	10 meter (zonder obstakels)
Afmetingen earbud	25,2 x 23,3 x 21,9 mm
Afmetingen oplaadcase	71,1 x 40,0 x 27,2 mm
Gewicht earbud	4,5 gram
Oplaadtijd earbud	1 uur
Oplaadtijd oplaadcase	1 uur (via Type-C)
Standbytijd	60 uur
Batterij capaciteit earbud	40 mAh
Batterij capaciteit oplaadcase	250 mAh
Input draadloze oplaadbasis	DC 5V/ 1A

Verpakkingsinhoud

- 1 x Wireless earbud pro L/R
- 1 x Oplaadcase
- 2 x Eartips (S/M/L), 2 x Wingtip (S/M), 1 x Casual tip
- 1 x Type-C Oplaadkabel
- 1 x Gebruiksaanwijzing

Reset

Wanneer een of beiden earbuds niet wilt connecten met je apparaat, reset dan beiden earbuds.

Stappen

1. Verwijder «Thunderz TZ-66» van je apparaat in de Bluetooth instellingen, en zet Bluetooth uit.
2. Zet beiden earbuds uit en stop deze in de oplaadcase.
3. Pak de earbuds uit de oplaadcase en zet de earbuds aan. Zet de Bluetooth op je apparaat aan en verbindt «Thunderz TZ-66» aan je apparaat via de Bluetooth instellingen.
4. De Bluetooth verbinding van de earbuds is nu gereset.

Note

Reset altijd de 2 earbuds tegelijkertijd.

Waarschuwingen



1. De earbuds kunnen niet ondergedompeld worden in water en je kunt niet douchen of zwemmen met deze earbuds.
2. Plaats de earbuds nooit in direct zonlicht of op warme/vochtige plekken.
3. Zet de earbuds uit wanneer je deze niet gebruikt.
4. Probeer het product niet te demonteren.
5. Laat de earbuds niet vallen of stoot deze niet tegen andere oppervlakken.
6. Wanneer het volume van de earbuds te lang op een te hoog volume staat, kan dat leiden tot gezondheidsklachten. Ben ervan bewust.

Earbuds plaatsen



1. Kies en bevestig de eartip die het best bij je oor past.
2. Bring de earbud in de binnenkant van je oor.
3. Draai de wingtip in je oorschelp en vind de meest comfortabele positie.

