

BandiO Rechargeable Wall Lamp Paris

With Motion Sensor

Parameters:

Power: 3W

Material: Aluminum Alloy

Battery Capacity: 3.7V 5200mAh

Charging input: DC5V 2A

Charging time: 7-8 Hours

Working time:

Approx. 15 hours (continuous on mode)

Approx. 1 month (motion detection mode)



Continuous On Mode:

- To activate the Wall Light push the switch into position "I"
- The Wall Light will burn constantly and will last +/- 10 hours before the battery is depleted.
- To deactivate the Wall Light push the switch into position "O"

Motion Detection Mode:

- To activate the motion detection, push the switch into position "II"
- The Wall Light will automatically turn on in the dark as soon as there is movement in the area. As soon as someone is nearby, the Wall Light will turn on for 20-30 seconds and then turn off automatically. The Wall Light stays on for 30 seconds until after the last movement.
- When it is light, the Wall Light will not turn on. The motion sensor only works in the dark.
- The Wall Light will work +/- 1 month in the motion detection mode before the battery is depleted.
- To deactivate the Wall Light push the switch into position "O"

BandiO “De draadloze sfeermakers”

Oplaadbare Wandlamp Paris

Met bewegingssensor

Parameters:

Power: 3W

Materiaal: Aluminium

Batterij Capaciteit: 3.7V 5200mAh

Oplaadpoort input: DC5V 2A

Oplaadtijd: 7-8 uur

Branduren bij volle batterij:

Ongeveer 15 uur (continu aan-modus)

Ongeveer 1 maand (Bewegingssensor-modus)



Continu aan-modus:

Om de wandlamp te activeren, schakelt u de schakelaar in positie “II”

De Wandlamp brandt constant en gaat +/- 15 uur mee voordat de batterij leeg is.

Om de wandlamp uit te schakelen, schakelt u de deze in de stand “O”

Bewegingsdetectie-modus:

Om de bewegingsdetectie te activeren, schakelt u de schakelaar in stand “I”

De Wandlamp gaat automatisch aan zodra er beweging in de ruimte is. Zodra er iemand in de buurt is, gaat de Wandlamp 30-45 seconden aan en gaat daarna automatisch uit. De Wandlamp blijft 45 seconden branden tot na de laatste beweging.

De Wandlamp werkt +/- 1 maand in de bewegingsdetectie modus voordat de batterij leeg is.

Om de wandlamp uit te schakelen, schakelt u deze in de stand “O”