
 <p>PRODUCT DESCRIPTION</p> <ul style="list-style-type: none"> • One button to control the motor. • The very strong vibrator motor and health silicone cover outside. <p>FEATURES</p> <ul style="list-style-type: none"> -Material: Silicone outside and ABS inside. -Width: 1.57" / 4cm. -Total length: 3.35" / 8.5cm. -Charging Time: 2hrs. -Working Time: 1-2hrs. -Max Noise Level: <50dB. -Vibration Patterns: 7 speeds licking+7 suction. 	<p>FUNCTIONS</p> <ul style="list-style-type: none"> • On/Off button (2): Power On/Off. • Button (1): after turning the toy on, short press to strengthen suction and licking. • Button (3): after turning the toy on, short press to weaken suction and licking. • Two functions work concurrently. • Recharging hole (4): when charging, the red light is flashing, when full charging, the red light stops flashing. <p>Maintenance</p> <ol style="list-style-type: none"> 1. Wash the product with normal temperature water and shower gel after use. 2. Wipe dry with a towel after washing, and then store in a ventilated, cool and dry place. 3. Full charge storage at the normal temperature, avoid high temperature and dirt. Do not place direct sunlight. 4. Please charge once every three months to avoid aging of battery if not used for long time. <p>Warning:</p> <ol style="list-style-type: none"> (1) Please charge the toy before use. (2) Please only use the water-soluble lubricants if need during use. Hand cream or silicone soluble lubricant may damage vibrator surface permanently. Please clean vibrators thoroughly after using, especially using lubricants. (3) Before use, please do read the instruction first. (4) Keep away from children, keep out reach of children. (5) Pregnant woman need to consult doctor before use. (6) Do not use if the silicone layer broken. <p>Attention: Do not share a same toy with others, since toy is belong to the personal hygiene product.</p>	<p>FAQ</p> <ol style="list-style-type: none"> (1) Toy's vibrator can not work when long press the button but the toy can not turn on? Normally, it is power shortage, please recharge. (2) The blue LED light can not turn on when vibrator is charging? Make sure to connect vibrator and charging device correctly, check/reconnect power supply and DC plug, or make sure if vibrator is fully charged. (3) Please shut down and restart when the program error occurs. <p>Cleaning, Shower, Safety</p> <ol style="list-style-type: none"> (1) Please thoroughly clean vibrator every time before and after use. Using massager special cleaner is clean is the best choice, also you can use warm water and antibacterial soap. (do not use the hot water, its temperature is over 80°C), then rinse residues using clear water, finally gently pat it with a dry towel or non-woven paper until vibrator totally dry. (2) Please do not use cleaner including alcohol, gasoline, acetone. (3) To avoid vibrator directly exposed to high temperature or sunshine. (4) Please keep vibrator in clean, dry place, and separate it from other vibrators. <p>Warranty</p> <ol style="list-style-type: none"> (1) One year warranty from the date of purchase, including product quality issues caused by product material, manufacturing process and product function. Please contact merchant (who you purchase the toy from), the merchant is responsible for the free replacement of new products for you. (2) Warranty is not including incorrect operation, accidental hit, long-term worn or issues caused by dismounting products. 	<p>Remarks:</p> <p>Please read all the following safety information before using or it may result in fire, electric shock, injury, or damage to products or other property.</p> <ol style="list-style-type: none"> 1. This product is only suitable for adults and it is prohibited of minors to use it. 2. Please stop using the product if there is any discomfort. 3. Regular inspection is necessary. Please stop using it if there is any damage. 4. This product contains sensitive electronic components, if the battery is dropped, burned, pierced or squeezed, it may be damaged. If you suspect that the product or battery is damaged, please stop using it. Because it can cause overheating or injury. 5. Do not attempt to replace the battery by yourself. The lithium battery of the product should be replaced by manufacturer or an authorized service provider. Improper replacement or repair may damage the battery, causing overheating or injury. The battery needs to be removed before the product is disassembled. The battery should be powered off before removing, and the battery needs to be disposed of safely, and please recycling it or disposed of separately from household waste. Do not incinerate the battery. 6. To charge the product, using the isolated cable in a power adapter that complies with applicable national regulations or one or more of the following: EN 301493 -34, IEC 62384, YD/T 1591-2009, CNS 15286, ITU L 1000 Or other applicable mobile phone power adapter (inter operability standards. Charge only with adapters that comply with applicable international and regional safety standards including IEC 62369-1, use damage cables, chargers, or charging in a humid environment can result in fire, electric shock, injury person or something others. Please be sure fully plugged into adapter when using USB charging. 7. The product meets applicable surface heat standards and limits. Even if these standards are met, prolonged exposure to hot surfaces can also cause discomfort or injury. Be especially careful if your body has conditions that affect your body's ability to sense heat. Must be careful when using it for people who are not sensitive to heat. <p>Packaging Details:</p> <p>Gift box, User Manual, Device, USB Data Cable.</p> <p>FC CE RoHS RECYCLE</p>
 <p>製品説明</p> <p>このデバイスには、モーターを制御する、非常に強い電動モーターと健康シリコーンカバーが備わっています。</p> <p>特徴</p> <ul style="list-style-type: none"> -材質: シリコン外面とABS内面。 -幅: 1.57cmです。 -総長: 3.35 / 8.5 cm. -充電時間: 2時間。 -動作時間: 1-2時間。 -最大ノイズレベル: <50dB -振動パターン: 7つの速度+7つの吸引を含めること。 	<p>機能</p> <ul style="list-style-type: none"> • オン/オフボタン(2)、電源オン/オフ。 • ボタン(1): おもちゃを付した後、短いプレス電圧と強められかちを強化するために。 • ボタン(3): おもちゃを付した後、短いプレス電圧と弱められるために。 • 2つの機能が同時に働きます。 • 充電再開窓(4): 充電するとき、赤い光が点滅し、完全充電、赤い光が点滅します。 <p>メンテナンス</p> <ol style="list-style-type: none"> 1. 充電後洗浄する使用後の水+シャワージェル。 2. 洗浄後はタオルで拭いてから拭き取られ、涼しい、乾いた場所に置く。 3. 充電での過充電警告+汚れを避けてください。傷のない直射日光。 4. 毎月3-5回充電を避けてください。長時間使用しない場合は電池の劣化。 <p>警告:</p> <ol style="list-style-type: none"> (1) ご使用前におもちゃを充電してください。 (2) 液体性の潤滑剤を使用してください。中に必要使用するクリームまたはシリコンオイル潤滑剤はバイブレーター表面を永久に傷つけることがあります。完全に乾いた状態に潤滑剤を塗布してください。特に潤滑剤の使用。 (3) 使用前に最初に読んでください。 (4) 子供たちを遠ざけ、子供の手を触らさない。 (5) 妊娠中は使用時に医師に相談する必要がある。 (6) シリコン層が破れた場合は使用しない。 <p>注意: 他人と同じおもちゃを共有しないでください。おもちゃは個人衛生製品に属しているので。</p>	<p>よくある質問</p> <ol style="list-style-type: none"> (1) コンパレトス時には製品のバイブレーターは動作できないボタンが赤いライトオンにすることはできませんか? 電圧は電圧不足ですので、充電してください。 (2) 青いLED照明は点灯しないバイブレーター充電できませんバイブレーターと充電装置と接続してください。 正しい電線、正しい電圧、チェックまたは、バイブレーターと完全に充電されるかどうか確認してください。 (3) レットアウトして内部掃除してください。 プロクターエラーが修正する。 <p>クリーニング、乾燥、安全</p> <ol style="list-style-type: none"> (1) 毎回製品を完全に清潔にし、清潔な使用の前に、シャワージェル+シリコーンオイルの潤滑剤+クリーナーシリコンに適用する潤滑剤は、また、するに必要です。乾燥と清潔に保つてください。 (お湯を使わないで)60℃以上。 その後、最後に乾かすか軽く拭いた水を使用して潤滑剤をリンスバイブレーターまで乾いたタオルや手拭き布で完全に乾かす。 (2) デュコールを含ませクリーナーを使用しないでください。アルコール、アセトン。 (3) 高温環境に直接露出されたバイブレーターを避ける。湿度または日光。 (4) 製品を清潔な場所に保管してください。他のバイブレーターから分離。 <p>保証</p> <ol style="list-style-type: none"> (1) 購入日から1年間の保証。 製品品質の問題を及ぶ製品材料、製造工程及び製造機械、商人に追加してください。あなたまたは、おもちゃを購入する新しい無料の交換を担当するあなたのため製造。 (2) 保証は間違いの操作を含みません。誤用の結果、長期にわたる着用または過度製品を取り出すことによって。 	<p>注意</p> <p>以下のすべての安全情報をよく読んでください。事故、けがや火災を招くことと損傷や人身事故または他の財産への損害。</p> <ol style="list-style-type: none"> 1. 本製品は大人に適用されるので未成年の使用を禁止します。未成年者の使用には許可を得てください。 2. 正確な使用が必要で、ご使用を中止してください。潤滑剤があるならば。 3. この製品は乾燥や電子部品を含んでいて、乾燥を避けて、涼しい、乾いた場所で乾かしてください。直射日光、直射日光を避けてください。傷のない直射日光。 4. この製品は乾燥や電子部品を含んでいて、乾燥を避けて、涼しい、乾いた場所で乾かしてください。直射日光、直射日光を避けてください。傷のない直射日光。 5. 自分のバイブレーターを交換しようとしてはいけません。製品のリチウム電池を交換すべきである。メーカーまたは認可されたサービスプロバイダーによって、手動での交換または修理は、潤滑剤を含めることとバイブレーターは、過熱や損傷を安全に。製品が修理されている間は、使用を中止する必要があります。製品が修理された後に確認する。そして、バイブレーターを完全に充電する必要があります。リチウム電池、又は充電回路を完全に充電後、バイブレーターを修理してください。 6. 正確な使用が必要で、ご使用を中止してください。潤滑剤があるならば。 7. この製品は乾燥や電子部品を含んでいて、乾燥を避けて、涼しい、乾いた場所で乾かしてください。直射日光、直射日光を避けてください。傷のない直射日光。 8. この製品は乾燥や電子部品を含んでいて、乾燥を避けて、涼しい、乾いた場所で乾かしてください。直射日光、直射日光を避けてください。傷のない直射日光。 <p>パッケージの詳細</p> <p>ギフトボックス、ユーザーマニュアル、デバイス、データケーブル、USBデータケーブル。</p>

 <p>製品説明</p> <p>このデバイスには、モーターを制御する、非常に強い電動モーターと健康シリコーンカバーが備わっています。</p> <p>特徴</p> <ul style="list-style-type: none"> -材質: シリコン外面とABS内面。 -幅: 1.57cmです。 -総長: 3.35 / 8.5 cm. -充電時間: 2時間。 -動作時間: 1-2時間。 -最大ノイズレベル: <50dB -振動パターン: 7つの速度+7つの吸引を含めること。 	<p>機能</p> <ul style="list-style-type: none"> • オン/オフボタン(2)、電源オン/オフ。 • ボタン(1): おもちゃを付した後、短いプレス電圧と強められかちを強化するために。 • ボタン(3): おもちゃを付した後、短いプレス電圧と弱められるために。 • 2つの機能が同時に働きます。 • 充電再開窓(4): 充電するとき、赤い光が点滅し、完全充電、赤い光が点滅します。 <p>メンテナンス</p> <ol style="list-style-type: none"> 1. 充電後洗浄する使用後の水+シャワージェル。 2. 洗浄後はタオルで拭いてから拭き取られ、涼しい、乾いた場所に置く。 3. 充電での過充電警告+汚れを避けてください。傷のない直射日光。 4. 毎月3-5回充電を避けてください。長時間使用しない場合は電池の劣化。 <p>警告:</p> <ol style="list-style-type: none"> (1) ご使用前におもちゃを充電してください。 (2) 液体性の潤滑剤を使用してください。中に必要使用するクリームまたはシリコンオイル潤滑剤はバイブレーター表面を永久に傷つけることがあります。完全に乾いた状態に潤滑剤を塗布してください。特に潤滑剤の使用。 (3) 使用前に最初に読んでください。 (4) 子供たちを遠ざけ、子供の手を触らさない。 (5) 妊娠中は使用時に医師に相談する必要がある。 (6) シリコン層が破れた場合は使用しない。 <p>注意: 他人と同じおもちゃを共有しないでください。おもちゃは個人衛生製品に属しているので。</p>	<p>よくある質問</p> <ol style="list-style-type: none"> (1) コンパレトス時には製品のバイブレーターは動作できないボタンが赤いライトオンにすることはできませんか? 電圧は電圧不足ですので、充電してください。 (2) 青いLED照明は点灯しないバイブレーター充電できませんバイブレーターと充電装置と接続してください。 正しい電線、正しい電圧、チェックまたは、バイブレーターと完全に充電されるかどうか確認してください。 (3) レットアウトして内部掃除してください。 プロクターエラーが修正する。 <p>クリーニング、乾燥、安全</p> <ol style="list-style-type: none"> (1) 毎回製品を完全に清潔にし、清潔な使用の前に、シャワージェル+シリコーンオイルの潤滑剤+クリーナーシリコンに適用する潤滑剤は、また、するに必要です。乾燥と清潔に保つてください。 (お湯を使わないで)60℃以上。 その後、最後に乾かすか軽く拭いた水を使用して潤滑剤をリンスバイブレーターまで乾いたタオルや手拭き布で完全に乾かす。 (2) デュコールを含ませクリーナーを使用しないでください。アルコール、アセトン。 (3) 高温環境に直接露出されたバイブレーターを避ける。湿度または日光。 (4) 製品を清潔な場所に保管してください。他のバイブレーターから分離。 <p>保証</p> <ol style="list-style-type: none"> (1) 購入日から1年間の保証。 製品品質の問題を及ぶ製品材料、製造工程及び製造機械、商人に追加してください。あなたまたは、おもちゃを購入する新しい無料の交換を担当するあなたのため製造。 (2) 保証は間違いの操作を含みません。誤用の結果、長期にわたる着用または過度製品を取り出すことによって。 	<p>注意</p> <p>以下のすべての安全情報をよく読んでください。事故、けがや火災を招くことと損傷や人身事故または他の財産への損害。</p> <ol style="list-style-type: none"> 1. 本製品は大人に適用されるので未成年の使用を禁止します。未成年者の使用には許可を得てください。 2. 正確な使用が必要で、ご使用を中止してください。潤滑剤があるならば。 3. この製品は乾燥や電子部品を含んでいて、乾燥を避けて、涼しい、乾いた場所で乾かしてください。直射日光、直射日光を避けてください。傷のない直射日光。 4. この製品は乾燥や電子部品を含んでいて、乾燥を避けて、涼しい、乾いた場所で乾かしてください。直射日光、直射日光を避けてください。傷のない直射日光。 5. 自分のバイブレーターを交換しようとしてはいけません。製品のリチウム電池を交換すべきである。メーカーまたは認可されたサービスプロバイダーによって、手動での交換または修理は、潤滑剤を含めることとバイブレーターは、過熱や損傷を安全に。製品が修理されている間は、使用を中止する必要があります。製品が修理された後に確認する。そして、バイブレーターを完全に充電する必要があります。リチウム電池、又は充電回路を完全に充電後、バイブレーターを修理してください。 6. 正確な使用が必要で、ご使用を中止してください。潤滑剤があるならば。 7. この製品は乾燥や電子部品を含んでいて、乾燥を避けて、涼しい、乾いた場所で乾かしてください。直射日光、直射日光を避けてください。傷のない直射日光。 8. この製品は乾燥や電子部品を含んでいて、乾燥を避けて、涼しい、乾いた場所で乾かしてください。直射日光、直射日光を避けてください。傷のない直射日光。 <p>パッケージの詳細</p> <p>ギフトボックス、ユーザーマニュアル、デバイス、データケーブル、USBデータケーブル。</p>
---	--	---	---