

HANDLEIDING DESIRE BUTTPLUG



NL

1. Laad de DESIRE BUTTPLUG volledig op.
2. Op de buttplug zie je één aan/uit knop. Houdt deze knop 3 secondes ingedrukt om het product in te schakelen (**NIET DE AAN KNOP OP DE AFSTANDSBEDIENING**).
3. Nadat de buttplug is ingeschakeld, druk dezelfde button (kort) in, om door de 10 verschillende vibreer- en de 3 stootstanden te rouleren.
4. Je kan de buttplug ook met de bijbehorende afstandsbediening bedienen. Houdt de aan knop (onderste button op de afstandsbediening) ingedrukt om de afstandsbediening te activeren.
5. De afstandsbediening heeft 2 knoppen:
 - 5.1 De **bovenste knop** is de 'vibreer button'. Hiermee kan je rouleren door de 10 verschillende vibreer snelheden
 - 5.2 De **onderste knop** is de 'aan button'. Hiermee activeer je de afstandsbediening, vervolgens kan de dezelfde knop ook gebruikt worden om de stootstand te activeren en te rouleren door 3 verschillende snelheden. Houdt deze knop ingedrukt om de DESIRE BUTTPLUG te deactiveren (Als deze al geactiveerd is).
6. Geniet van je aankoop! Ook te gebruiken op de clitoris/tepel/vagina.

EN

1. Fully charge the DESIRE BUTTPLUG.
2. On the buttplug you see one on/off button. Press and hold this button for 3 seconds to turn on the buttplug (**NOT THE ON BUTTON ON THE REMOTE CONTROL**).
3. After the buttplug is turned on, press the same button (short) to cycle through the 10 different vibration and 3 thrust modes.
4. You can also operate the buttplug with the corresponding remote control. Press and hold the on button (lower button on the remote) to activate the remote control.
5. The remote control has 2 buttons:
 - 5.1 The **top button** is the 'vibrate button'. This allows you to rotate through the 10 different vibration speeds
 - 5.2 The **lower button** is the 'on button'. This activates the remote control. The same button can also be used to activate the thrusting mode and to rotate through 3 different speeds. Press and hold to deactivate the DESIRE BUTTPLUG (if already activated).
6. Enjoy your purchase! Can also be used on the clitoris/nipple/vagina.