



plug, then pulg the charger into an electrical outlet.

- Non-rechargeable battery can not be recharged.
- Do not use different types of batteries.
- Batteries should be loaded correctly according to the polarity indication.
- Exhausted batteries should be removed from the toy.
- The supply terminals should not be short-circuited.
- Do not use old and new batteries together.
- Please take out the batteries when it is not being used.

Please keep this package well for your future reference since it contains important information.


SPECIFICATIONS COLOURS AND CONTENTS MAY VARY FROM ILLUSTRATIONS







صنعت وفقا للمواصفات والمعايير العالمية



اجزاء صفيرة غير مناسبة للأطفال دون سن الثالثه.

ويجب تشغيل اللعبة عن طريق اشراف الوالدين أؤ البالفين.

تبعد عن مصادر اللهب و أشعة الشمس و أي المؤثرات الخارجية.

A WARNING:

CHOKING HAZARD -Small parts.


Not for children under 3 years.



PELIGRO DE AHOGARSE. Contiene partes pequeñas. No recomendado para niños menores de 3 años.



NOT SUITABLE FOR CHILDREN UNDER 3 YEARS DUE TO SMALL PARTS



المطعاة الصغيرة COUNTRY OF ORIGIN:CHINA بلدالمنشاة: الصبين









MADE IN CHINA