



1 Directions For Use

1. Press the switch for 1.5s, comes the first mode, the light on.
2. In the boot state, press switch to change 10 vibrating modes circularly.
 - This product has memory function, when it turns on, vibrating mode keeps the same as before turn off, change to your favorite modes. Double click switch to the first mode.
3. Press switch for 1.5s to turn off after a short vibration, then the light turns off.

2 Charging Instructions


The light flashes before no power, indicating it needs to charge, connect the magnetic port with cable.



3 Functions

- | | |
|---------------------|-------------------|
| Soft Body | Private & Quiet |
| Smart and Portable | Magnetic Charging |
| Food grade silicone | 10 frequencies |

4 Frequency Show




5 Cleaning Instructions


Clean it with cleaning fluid after use, please use temperate shower gel, soap or professional cleaning fluid, kneading vibrator gently by hands, then wash it with $\leq 60^{\circ}\text{C}$ water, finally dry it with a clean towel and put it into storage bag.

Please follow above ways before use.

6 Game Suggestions



GAME-A



GAME-B