


ASSEMBLY

by an adult.

distance of not less
space in front of

ce between the



COUNTING

ceiling / beam should sit well.

ld be fitted with a plastic sleeve that prevents metal-to-metal
friction.

e that they are perfectly folded in half and then postponed.
rly. Improper assembly or damage to the mount may lead to
read these instructions before installation.

adjustment:

ld choose the length of the ropes.

he manufacturer will not be liable in the event of an accident.

DAMAGE INSTRUCTIONS

upholstery with a mild detergent. The swing should hang in a
ace.

se store it in its original box.

ty:

year warranty

rer:

o. o.

65 BIALYSTOK

POLAND

