


Dynter.


AV23-G MANUAL



Box Contents



Motor




Chassis




Blade



Support pipe



Front net



Rare net



Bolt



gasket



Bolt




Manual

Table of Contents

1. Product overview
2. General Cautions
3. Installing the product
4. Maintenance
5. Function
6. Operating instructions
7. Technical specifications

1. Product Overview




2. General Cautions

Read and save these important safety instructions before using this fan, when using electrical appliances, basic safety precautions should always be followed including the following:

1. Use this fan only as described in this manual. Other uses not recommended may cause fire or electric shocks.
2. This product is intended for HOUSEHOLD USE ONLY and not for commercial, industrial or outside use.
3. To protect against electrical shocks, do not place fan in window, immerse unit, plug or cord in water, or spray with liquids.
4. Unplug the fan from the outlet when not in use, when moving fan from one location to another and before cleaning.
5. Do not operate the fan in the presence of explosive and/or flammable fumes.
6. Do not place the fan or any parts near an open flame, cooking or other heating appliance.
7. Avoid contact with moving fan parts.
8. To disconnect, grip the plug and pull it from the wall outlet.
9. The use of attachments is not recommended and may cause hazards.
10. Always use on a dry, level surface.
11. Do not operate if the fan housing is removed or damaged.
12. Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.
13. Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
14. The appliance is not to be used by children or persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.
15. Close supervision is necessary when any appliance is used by or near children. Children being supervised not to play with the appliance.


3. Installing The Product

1




Install the lifting pipe assembly into the base along the holes in the base (a), lock the pipe with a bolt and gasket, and secure the base (b).


2



Connect the main body with the lifting pipe, and then lock it with bolts (a, b, c).




3




Rear mesh combination: twist out the leaf bundle clockwise and counterclockwise


Out of the net bundle, put the back net cover into the three positioning columns of the front net cover of the motor. Then fix it clockwise with the net bundle. (a, b)

4

Fan blade combination: Insert the fan blade into the motor shaft center and align the back of the fan blade with the shaft center. The latch is pressed into the bottom and fits perfectly. Then twist the blade in a counterclockwise direction. The entry is fixed. (a, b)

5

Front net assembly: Gradually plug the assembled front net cover components into the rear net All the way around, so that the front and rear mesh perfectly fit. Then lock the ring screw to fix the front and rear mesh covers. (a, b)

6

4. Maintenance




Important: Always unplug the device from the mains before cleaning. To maximize the efficiency of the device, clean regularly

Cleaning the body


Use a soft, damp cloth to wipe the body clean. Never use aggressive chemicals, gasoline, detergents, chemically treated cloths, or other cleaning solutions. These all could possibly hurt the casing material.

Cleaning the fan blades


1. Be sure your fan is in the OFF position.
2. Unplug the fan before cleaning.
3. Use only a soft, damp cloth to gently wipe the fan.
4. DO NOT immerse the fan in water and never allow water to enter the Motor Housing.
5. DO NOT use gasoline, paint thinner or other chemicals to clean the fan.
6. Remove the screw located in the grill of the fan.
7. Unlatch the clips on the grill and remove the front grill carefully.
8. Replace by placing the grill back and securing the latch.
9. Secure the grill with the screw.





5. Functions





6. Operating Instructions

 In the power-on state, press this key to start the fan. Press the fan again to close. When the fan is powered on all the time, it will automatically remember the working state before shutdown, and when it is restarted after power failure, it will run at 1st wind level.

 In the startup state, press this key to start the fan swing head; Press it again to turn off the swing head function. Pressing this key in the shutdown state does not work.

 Press this key to set the air volume tap during startup or reservation. The selection sequence is as follows:




 Press the "timing" key on the remote control in the boot state, and you can set the timing shutdown time by pressing the "timing" key on the on the control panel



Long press the On/Standby button for 3 seconds to enter the off-screen state (including the power indicator), and then press any key to wake up.

7. Technical Specifications



Single product size: 350 x 350 x 1160 mm
Outer box size: 595 x 210 x 370 mm
Net weight of single product: 4.9kg
Gross weight of single product: 5.6kg

Rated Voltage	220-240V
Rated Frequency	50-60Hz
General Power	45W

