## Fill the outer tube with air 50cm Fill water here 66cm **Water Valve** Air Valve | 0

Step1
Fill water in middle part

Step2
Fill air in the outer tube

