




LAGOON

# RECOVERY TUB

## INSTALLATION INSTRUCTIONS



1. INSERT THE THICK POLES INTO THE HOLES ON THE SIDE OF THE RECOVERY TUB



2. PUSH EACH POLE UP THROUGH THE HOLE UNTILL ONLY THE BOTTOM OF THE POLE IS SHOWING.



3. INSTALL THE RUBBER RING ON THE DRAIN AND SCREW ON THE TAP AS TIGHT AS POSSIBLE.



4. FIRMLY INSERT THE END OF THE PUMP INTO THE BLOW HOLE OF THE UPPER RING.



5. PUMP UP UNTIL ALL KINKS IN THE INFLATABLE UPPER RING ARE REMOVED.



6. INSTALLATION IS COMPLETE

WE RECOMMEND CHANGING THE WATER IN YOUR RECOVERY TUB EVERY 3-5 DAYS