

EN - For indoor use only. The external flexible cable or cord of this luminaire cannot be replaced, if the cord is damaged, the luminaire shall be destroyed. The lamps are not replaceable. This lighting chain is not to be destroyed. Inaccessible for children. This light set has 3 functions: 1. "ON" for continuously switched on; 2. "TIMER" for switching the light on/off automatically (5 hours on and 18 hours off); 3. "OFF" for continuously switched off.

DE - Nur für den Einsatz im Innenbereich (im flexible Kabel ohne Beschädigung ist, ist das Beleuchtungsgerät zu beschädigen. Die Lampen können nicht ausgetauscht werden. Diese Leuchte ist kein Kinderspielzeug. Bitte für Kinder unzugänglich anbringen. Dieses Beleuchtungsgerät hat 3 Einstellungen: 1. "ON" - Dauerbetrieb, 2. "TIMER" - automatisch: 5 St. an und 18 St. aus, 3. "OFF" - dauerhaft aus.



2 x AA (Not included)



Itemnr.: 231125



CBQ P.O BOX 15
1735 ZD WAARLAND (NL)

21

