



MANUAL FOR MACARONS, BIG MACARON, DROPS AND COOKIES

To ensure you and your family can enjoy this Wobbel Candy product a lot, and for a long time we urge you to read this manual carefully.

Wobbel Candy products are mainly made of natural materials. Due to this they are all unique. Please check them upon arrival for damages. Contact us within 14 days if you have any comments.

A printable user's manual in many languages can be downloaded at www.wobbel.com

Keep these instructions for future reference.

FOR GAMES AND PLAY SUGGESTIONS: #WOBBELCANDY

AGE

Wobbel Candy Macarons, Big Macaron and Cookies are designed and CE/ASTM/AUS certified for all ages.

Wobbel Candy Drops are designed and CE/ASTM/AUS certified from 10 months and up.

They are designed as handheld toys. Other uses have not been tested and certified, so Wobbel BV cannot guarantee its safe use when used in other ways.

Make clear rules about what can and can't be done with it.

WARNINGS

1. Wobbel Candy products are very active toys and, as always with these kinds of toys; parental or adult supervision is required. Especially for children of younger ages.
2. Don't throw or roll Wobbel Candy products towards people or animals to prevent injury.
3. Be careful around glass and other fragile materials to prevent breakage and injury.
4. If the wood is damaged, chipped or has splinters, don't use the toy to prevent injury.
5. Don't put Wobbel Candy products or any of its parts into the mouth to avoid choking.
6. Make sure there is enough free space around the play area (including other children) to prevent injury.
7. The materials used are subject to wear. Ensure your child doesn't stick loose pieces in their mouth, which could result in choking. Remove them when present.

USAGE GUIDELINES

Wobbel Candy Products are designed for indoor use. They can be used outdoors but will wear quicker.

Never leave outside, because water and moisture will eventually damage the wood and paint.

Wobbel Candy products can get damaged by the use on hard and or irregular surfaces.

Especially pay attention with stone surfaces, to prevent chips, splinters and the wear of the lacquer.

Take care that vulnerable surfaces can get scratched or damaged by the wood of the toy.

Don't store them near a heat source like central heating and don't store them in damp environments like a bathroom or an unheated shed or garage.

Wood discolors under the influence of (bright) light. Keep this in mind. This is a natural process.

Our water based lacquers can wear off (partly) over time. We think this adds character. It won't effect its use.

CLEANING AND MAINTENANCE

If needed they can be cleaned with a damp cloth, combined with a mild detergent if necessary.

We had great results with a natural soap. Don't wet the wood too much because that could result in damaging the lacquer or wood.

It's important to wipe them with a dry cloth after cleaning and let them dry thoroughly.

There's no need for any special maintenance.

ADDITIONAL INFORMATION

Wobbel Candy products are made from PEFC certified maple or beech wood, finished with child friendly water based lacquers and the bands are BPA free silicone.

The packaging is made from recycled cardboard and this manual is printed on sustainable paper.

Wobbel BV can't be held responsible and accountable for physical and financial damage caused by using Wobbel Candy products. Use active toys with care and under supervision of an adult.

They look tasty, but they're not for eating. But they are food for play!

Wobbel Candy is a registered brand by Wobbel BV.
Wobbel BV owns all model rights of Wobbel Candy products.
The name Wobbel Candy and its logos are protected brands
and can't be used without permission by Wobbel BV.

Dutch design, made in Germany
www.wobbelcandy.com | info@wobbel.com | +31641273330
Uraniumweg 15A 3812RJ Amersfoort The Netherlands

