

LED Taper Candle Light




Scope of delivery

- Candles
- Remote control
- Batteries: 3V CR2025 (already inserted)

Installation Instructions

1. Remove the packaging.
2. Insert the batteries, as shown in the figure.
Please insure that the batteries are well inserted.
3. If the candle flame is not straight, please adjust it by yourself.



Please remove the batteries, if not used for extended periods of time.
This candle must use with holder to ensure the candle not fall off.

Operation

1. Open the battery compartment on the bottom of the candle.
2. Insert the 1AA batteries in the battery compartment with the correct direction and polarity, and close the compartment.
3. Before using the remote control, to turn on the LED-light by press the bottom of the candle.
4. Set the candle at the desired place.
5. Press the "ON" button on the remote control to turn on your light.
6. Press "2H/4H/6H/8H" button on the remote control to set your light with 2/4/6/8 hours timer after you fixed the light.
7. Press the "Candle" button to set your flicking light.
Press the "Light" button to set your steady light.
8. To use dimming function, press "★" to make the light weak, total 3 grades: press "☼" to make the light strong, total 3 grades.
9. Press the "OFF" button on the remote control to turn off your light.
10. You can also activate the Candle/ Light/★/☼ functions without a timer.
The candles then light up continuously until the function OFF is switched.

Timer Function

1. For timer function it will only be realized by using the remote control.
Be sure to light all the candles at the same time while pressing the timer button, if the candles with the AA do not respond to the timer function safely, a new battery should be inserted.
2. After 2/4/6/8 hours run time, the LED turns off automatically.
3. The next day, the LED at the same time on again.
4. This process is repeated endlessly. Stop the timer by pressing the OFF switch.
5. Switch on without timer leads to continuous lighting of the candle, until the switch is "OFF".

Cleaning and Maintenance

Use a soft dry cloth for cleaning.
By time and temperature, the product color may exist fade or come off wax oil, it is wax feature, does not affect the normal use.

Safety information

1. Not suitable for children!
2. Avoid direct eye contact with the LED.
3. The installed LEDs are not interchangeable.
4. If the product will not be used for a long time, please remove the battery.
5. Keep away from water and moisture, use only indoors at, use only in dry environment.
6. Please keep the LED candles away from high temperature environment because they are made of real wax with a melting point of 58°C.
7. When the battery is low, its remote control distance may be shortened, after replacing the new battery, it can continue to use normally.
8. Do not light the electronic candle while it is still in the package
9. Do not use if the product is damaged.

Specifications

3V DC for each candle, 3V for remote control (1 type AA batteries and 1 type CR2025 batteries)

Disposal



Dispose of the packaging in an environmentally friendly manner and take it to a recycling centre.



Batteries should be removed prior to disposal of the article and disposed of separately from the article at suitable collection points.



This article is governed by the European Directive 2012/19/EU on waste electrical and electronic equipment (WEEE). Do not dispose of these articles as non-hazardous domestic waste, but rather in an environmentally friendly manner via an officially approved waste disposal company.

⚠ WARNING

INGESTION HAZARD: This product contains a coin battery.
Death or serious injury can occur if ingested.
A swallowed coin battery can cause internal chemical burns in as little as 2 hours.

Keep new and used batteries **OUT OF REACH OF CHILDREN**
Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body.

