

QUICK START GUIDE

Step 1: Activate the Tea Light

Use the switch located on the bottom cap to turn the tea light on or off.

IMPORTANT: Remove all plastic protection layers before use.

Step 2: Activate the Remote

Remove the plastic insulation strip from the remote control to enable functionality.

BATTERY CHARGING GUIDE

- This product features a built-in rechargeable battery. Use the provided charge station to charge up to six tea lights simultaneously.
- An indicator light is located at the bottom of the tea lights electronic component. It glows red while the tea light is charging and turns off once the battery is fully charged.
- To protect the battery, avoid overcharging and do not use the tea light while it is charging.

REMOTE CONTROL GUIDE

- **ON/OFF:** Turn the tea light on or off. Make sure the power switch on the bottom of the tea light is turned on before using the remote control.
- **TIMER:** Set an automatic on/off function for 2, 4, 6, or 8 hours.
 - For example, if the timer is set for 2 hours at 8:00 PM, the tea light will automatically turn off at 10:00 PM.
- **MODE:** Choose 'Candle' for a flame effect or 'Light' for light without a flame effect.
- **Brightness:** Decrease the brightness with the left Minus button and increase the brightness with the right Plus button.

IMPORTANT: Each tea light can be controlled individually using the remote control, as long as they are not placed too close together. Simply point the remote at the specific tea light and select the desired setting. Please note that the remote has a long range and may operate multiple tea lights at once if they are within its reach.

TIPS AND WARNING

- This tea light set is suitable for indoor use only.
- Remove all plastic protection layers before using the tea lights.
- Charge the batteries of the tea lights or change the batteries of the remote control when they run out.

WARNING: This product contains small parts. Keep out of reach of children to prevent choking hazards.

AURAE

Thank you for your purchase!

Your satisfaction is our greatest success. If you have any questions or concerns, please don't hesitate to contact our customer support team.

SNELLE STARTGIDS

Stap 1: Activeer het theelichtje

Gebruik de schakelaar op de onderkant om het theelichtje aan of uit te zetten.

BELANGRIJK: Verwijder alle plastic beschermlagen voor gebruik.

Stap 2: Activeer de afstandsbediening

Verwijder de plastic isolatiestrip van de afstandsbediening om deze te kunnen gebruiken.

GIDS VOOR HET OPLADEN VAN BATTERIJEN

- Dit product heeft een ingebouwde oplaadbare batterij. Gebruik het meegeleverde oplaadstation om maximaal zes theelichtjes tegelijk op te laden.
- Onderaan de elektronische component van het theelichtje zit een indicatielampje. Het brandt rood terwijl de kaars wordt opgeladen en gaat uit zodra de batterij volledig is opgeladen.
- Voorkom overladen en gebruik het theelichtje niet tijdens het opladen om de batterij te beschermen.

HANDLEIDING AFSTANDSBEDIENING

- **AAN/UIT:** Zet het theelichtje aan of uit. Zorg ervoor dat de aan/uit-schakelaar aan de onderkant van het theelichtje aan staat voordat u de afstandsbediening gebruikt.
- **TIMER:** Stel een automatische aan/uit-functie in voor 2, 4, 6 of 8 uur.
 - Als de timer bijvoorbeeld is ingesteld op 2 uur om 20:00 PM, gaat het theelichtje automatisch uit om 22:00 PM.
- **MODUS:** Kies 'Candle' voor een vlameffect of 'Light' voor licht zonder vlameffect.
- **Brightness:** Verlaag de helderheid met de linker Minus-knop en verhoog de helderheid met de rechter Plus-knop.

BELANGRIJK: Elk theelichtje kan afzonderlijk worden bediend met de afstandsbediening, zolang ze niet te dicht bij elkaar staan. Richt de afstandsbediening op het theelichtje en selecteer de gewenste instelling. Houd er rekening mee dat de afstandsbediening een groot bereik heeft en meerdere theelichtjes tegelijk kan bedienen als ze zich binnen zijn bereik bevinden.

TIPS EN WAARSCHUWING

- Deze theelichtset is alleen geschikt voor gebruik binnenshuis.
- Verwijder alle plastic beschermlagen voordat je de theelichtjes gebruikt.
- Laad de batterijen van de theelichtjes op of vervang de batterijen van de afstandsbediening als ze leeg zijn.

WAARSCHUWING: Dit product bevat kleine onderdelen. Buiten bereik van kinderen houden om verstikkingsgevaar te voorkomen.

AURAE

Bedankt voor uw aankoop!

Uw tevredenheid is ons grootste succes. Als je vragen of zorgen hebt, aarzel dan niet om contact op te nemen met onze klantenservice.