

10 inch writing area

Put out the pen from
the down side

2. Avoid using sharp or sticky materials to prevent damage;
Avoid the intense impact of vertical or other objects.
3. Please use no-dust cloth to wipe clean.
4. Do not disassemble this product without professional help.
If the product fails, please contact the manufacturer for maintenance.
5. Do not use unsafe and mismatching accessories.



WA
CHOKING HAZARD
Not for children

