

## **NEDERLANDS: HANDLEIDING HomeShopXL Aquarium Pomp met Luchtsteen Set AP-15000**

### **Producteigenschappen:**

1. Dubbele behuizing, heeft een rustige toon, slechts 30dB.
2. Gebruik de potentiometer om het vermogen aan te passen, eenvoudig te hanteren.
3. Bevat AC-motor, speciale subassemblage van synthetisch rubber, hoge druk, maximale output, constante parameters.
4. Professioneel ontwerp, rationele constructie, mooie vorm. ABS-behuizing, hoge impact, lange levensduur.

### **Belangrijk tijdens gebruik:**

1. Sluit de pomp niet aan op een andere spanning dan aangegeven op de pomp.
2. Nooit oliën of smeren.
3. De luchtpomp moet boven het waterniveau worden geplaatst. Als dit niet het geval is, zorg er dan voor dat er een terugslagklep op de luchtslang is gemonteerd om te voorkomen dat water terug in de luchtpomp wordt geheveld.
4. Haal onmiddellijk de stekker uit het stopcontact als de pomp in het water valt.
5. Als het netsnoer beschadigd is, moet het worden vervangen door de fabrikant, zijn serviceagenten of een vergelijkbaar gekwalificeerd persoon om elektrisch gevaar te voorkomen.

### **Installatie:**

Plaats uw luchtpomp boven het waterniveau in verticale of horizontale positie. Als u hem onder het waterniveau plaatst, moet u een terugslagklep gebruiken. Zo voorkomt u dat er water terugstroomt als de stroom uitvalt.

### **Operatie:**

Uw luchtpomp is niet bedoeld voor gebruik in water. Plaats de luchtpomp nooit in water!!

**Gevaar:** als de luchtpomp in het water valt, koppel deze dan los van het netstroom voordat u deze verwijdert.

### **Onderhoud:**

Hoe de luchtpomp los te koppelen:

A-Verwijder de slang die op de luchtpomp is aangesloten;

B-Koppel de stekker uit het stopcontact.

## **ENGLISH: MANUAL HomeShopXL Aquarium Air Pump with Airstone Set AP-15000**

### **Product features:**

1. Double casing, have quiet tone effect.
2. Use potentiometer to adjust input power, easy handle.
3. Use AC motor, special-purposed synthetic rubber subassembly, high pressure, max output, constant parameters.
4. Professional design, rational construction, nice shape. ABS housing, high impact, long service life.

### **Caution:**

1. Do not connect to any voltage other than shown on the pump.
2. Do not oil at any time.
3. Air pump must be placed above water level. If not, ensure that a one way check valve is fitted to the air tube to prevent water from syphoning back into air pump.
4. Disconnect the plug immediately if the pump falls down into the water.
5. If the power supply cord is damaged, it must be replaced by the manufacturer or its service agents or a similarly qualified person in order to avoid electrical hazard.

### **Installation:**

Place your air pump above the water level in vertical or horizontal position, if you place it below the water level you must use a check valve, this way you'll avoid any backflow of water when the current fails.

### **Operation:**

Your air pump isn't intended to be used in water. Never place the air pump in water!!

Danger: in case the air pump falls in the water, disconnect the plug before you remove it.

### **Maintenance:**

How to disconnect the air pump:

A-Remove the tubing connected to the air pump;

B-Disconnect from the mains.