


# Multifunctional meat thermometer user manual

## ◆ Product diagram



## ◆ Product specifications

- Temperature measurement range:  $-25^{\circ}\text{C} \sim +250^{\circ}\text{C}$  ( $-13^{\circ}\text{F} \sim +482^{\circ}\text{F}$ )
- Temperature accuracy:  $\pm 1^{\circ}\text{C}$  ( $0 \sim 100^{\circ}\text{C}$  range)
- Positive timing range: 00:00 ~ 99:59 (unit: minutes and seconds)
- Countdown range: 00:00 to 99:59 (unit: minutes and seconds)
- Power supply: AAA 1.5V\*1
- Probe wire length: 1 meter, detachable (probe wire heat-resistant up to  $300^{\circ}\text{C}$ )

## ◆ Instructions

### 1. How to switch the machine

Toggle the switch on the back of the machine to the ON position to turn it on, and the OFF position to turn it off.

### 2. How to use the machine in temperature mode

① After turning on the machine, insert the probe into the right port of the machine, the left side of the screen displays the current temperature, and the right side is the preset alarm temperature. Press the ▲ and ▼ keys to adjust the alarm temperature downwards. When the current temperature exceeds the set alarm temperature, the machine will sound an alarm (displayed on the screen), press any key to stop the alarm.

② Press °C/°F key to switch between Celsius/Fahrenheit display.

### 3. How to use in timer mode

① Toggle the button on the back of the machine to the TIMER gear to enter the timer mode.

② The screen displays 00 (MIN): 00 (SEC), press the MIN key to adjust the minute value, press the SEC key to adjust the second value (press the MIN and SEC keys at the same time to clear the value), press the S/S key to start the countdown.

③ Press S/S key to start timing. (Press the MIN and SEC keys at the same time to clear the value)

## ◆ Attention

- The back of the machine is equipped with a strong magnet, so that it can be absorbed in the refrigerator or oven.
- When the screen display is not clear, please replace the battery in time.