

: 80X100mm

Mini LED Party Light Manual

Manual of remote controller

Turn on/off

Stop / start rotating

All colors flashing

Menu of Music
controlling effect and function by choosing A1, A2, A3, A4, A5, A6



No function

Sound-activated modes
MUSIC 1: sound-activated color effect
MUSIC 2: sound-activated color lighting
MUSIC 3: sound-activated music lighting

Motor rotating speed
1: normal speed
2: fast speed

Feature set

Mode	Function	Content
A1	EFFECT MODE	Auto mode
A2		Red on
A3		Green on
A4		Blue on
A5		Two-color mode cycle
A6		Color gradient
AF		Changing slowly cycle with white
MUSIC 1	MUSIC CONTROL	Sound-activated color
MUSIC 2		Sound-activated color changing
MUSIC 3		Sound-activated music lighting
FASTER	FUNCTION CONTROL	Light mode

Note

Remote controller must point the IR signal receiver without barriers when operating.
Remote control doesn't fit the device when 1 second delay when switch to other lighting patterns.