

Manual URGOODS Spy Pen

Important remark: the manual in the packaging is more comprehensive, more extensive

Instructions for use

Video mode: Press the top function button until the blue indicator turns on, the pen camera will start video-taking after the blue light flashes 3 times. The light would be off when the video-taking is going on. Press the function button one more time, video taking ends, the blue light would be back again (stand by mode). If you press the function button one more time, the pen camera will start video taking again.

Picture mode: When the pen is in video mode, press the function button once, video taking ends, the blue indicator will stay on. Press the button twice, the light will flash once, a photo will be taken, and the blue indicator will continue to stay on.

How to play video?

1. Connect to the computer via USB cable, and then use the player to play the video.
2. Remove the SD card, use a card reader to connect to the computer, and then play the video.

How to charge the hidden gear camera?

1. Connect to the USB port on the computer or use a 5V power supply.