

Instruction For Use

1. Place sharpener on its rubber feet on a level, non-slip surface.
2. Hold the sharpener handle part in such a way that thumb and index most and apply light downward pressure.
3. Introduce the knife blade into the slot horizontally at a 90 angle. From the handle end starting light pressure, draw the knife through the rollers in the direction of the arrow towards your body only till the blade tip. Depending on the degree of the bluntness, repeat procedure up to five times.
4. Check sharpening results by performing a cutting test with a piece of paper.
5. Do not dry sharpener as this can cause damage.
6. Sharpener is not suitable for sawteeth or special knives.
7. The angle of the sharpening rollers has been set for western household knives. A different angle is often need to sharpen Asian knives (e.g. Santoku knives) and achieve optimum sharpening results.

