



QUICK START GUIDE GUIDE DE DÉMARRAGE RAPIDE

IMPORTANT READ BEFORE USING **À LIRE** AVANT TOUTE UTILISATION


Any Questions? Des questions ?
turtlebeach.com/Recon50 | turtlebeach.com/Support

Package Contents Contenu de la boîte



Recon 50 Headset
Casque Recon 50

Removable Mic Boom
Microphone amovible



PC Splitter Cable
Câble séparateur PC

In-Line Controls Câble avec commandes intégrées

Mic Mute Switch

Switch to to mute the microphone.

Bouton de coupure du microphone sélectionnez pour couper le micro.

Master Volume Adjusts the master volume of the incoming game and chat audio.

Volume principal règle le volume principal du jeu et du chat vocal entrant.



PC/Mac & Mobile Setup Configuration PC/Mac & Mobile



Xbox One Setup Configuration Xbox One



Note/ Remarque :

The Recon 50X requires the NEW Xbox One Controller (with 3.5mm headset jack). Purchase the Ear Force Headset Audio Controller from turtlebeach.com for use with the original Xbox One Controller.

Le casque Recon 50X nécessite la NOUVELLE manette Xbox One (avec 3,5mm casque jack). Pour toute utilisation avec la manette Xbox One d'origine, l'adaptateur audio pour casque Ear Force est nécessaire. Disponible sur turtlebeach.com.

For detailed setup instructions visit:
Vous trouverez un guide d'installation détaillé à l'adresse
turtlebeach.com/Recon50



PS4™ Setup Configuration PS4™



1. Go to Settings >> Devices >> Audio Devices
2. Select Headset Connected to Controller for Input & Output Device
3. Set Output to Headphones to All Audio
4. Set Volume Control (Headphones) level to maximum
5. Select Adjust Microphone Level and follow the on-screen instructions to calibrate your microphone

1. Aller Paramètres >> Périphériques >> Périphériques audio
2. Dans Paramètres d'entrée et Périphérique de sortie, sélectionner Casque branché à la manette.
3. Sélectionner Sortie vers le casque, sélectionner Tout audio
4. Le niveau de volume du périphérique Réglage du volume (casque) doit être au maximum.
5. Sélectionner Régler le niveau du microphone et suivre les instructions à l'écran pour régler votre microphone

ES

1. Ve a Configuración >> Dispositivos >> Dispositivos de sonido
2. Selecciona los auriculares conectados al mando para los dispositivos de entrada y salida
3. Configura la salida de los auriculares a todos los sonidos
4. Configura el nivel del control de volumen (casque) al máximo
5. Selecciona Ajustar el nivel del micrófono y sigue las instrucciones para calibrar el micrófono

IT

1. Selezionare Impostazioni >> Dispositivi >> Dispositivi audio
2. Selezionare lo cuffie collegato al controller come dispositivo di ingresso e di uscita
3. Impostare l'opzione Riproduci l'audio tramite cuffie su Tutto l'audio
4. Impostare il livello di Controllo del volume (cuffie) al massimo
5. Selezionare l'opzione Regola il livello del microfono e seguire le istruzioni a schermo per calibrare il microfono

PT

1. Go to Settings >> Devices >> Audio Devices
2. Select Headset Connected to Controller for Input & Output Device
3. Set Output to Headphones to All Audio
4. Set Volume Control (Headphones) level to maximum
5. Select Adjust Microphone Level and follow the on-screen instructions to calibrate your microphone

NL

1. Ga naar Instellingen > Apparaten > Audioapparaten
2. Selecteer de headset die is aangesloten op de controller voor zowel in- als uitvoerapparaat
3. Stel de uitvoer in op Hoofdtelefoon naar alle audio
4. Stel Volumebeheering (hoofdtelefoon) in op maximaal
5. Selecteer Microfoonniveau aanpassen en volg de instructies in beeld om je microfoon te kalibreren.

DE

1. Wählen Sie Einstellungen >> Geräte >> Audiogeräte
2. Wählen Sie unter Eingabe- und Ausgabe-Gerät das mit dem Controller verbundene Headset aus
3. Stellen Sie die Ausgabe an Kopfhörer auf Gesamtton aus
4. Stellen Sie die Lautstärkeverstellung (Kopfhörer) auf Maximum ein
5. Wählen Sie die Option zur Einstellung des Mikrofonpegels und folgen Sie den Anweisungen zur Kalibrierung Ihres Mikrofons

SE

1. Gå till Inställningar >> Enheter >> Lydsenheter
2. Välj Headset anslutet till handkontroll som in- och utskåtsenhet
3. Ställ in Utgåva till Hörlurar till All ljud
4. Ställ in volymkontroll (Hörlurar) till maximal nivå
5. Välj Justera mikrofonnivå och följ instruksionserna på skärmen för att kalibrera din mikrofon

DK

1. Gå til Indstillinger >> Enheder >> Lydenheder
2. Vælg Headset tilsluttet til controller under Input- og output-enheder
3. Vælg Send til Hovedtelefoner for Alt lyd
4. Indstil lydstyrken (Hovedtelefoner) til det maksimale niveau
5. Vælg Tilpas mikrofonstyrke, og følg instruksionserne på skærmen for at kalibrere din mikrofon

Regulatory Compliance Statements for the EAR FORCE Recon 50 Headset Federal Communications Commission (FCC) Compliance Notice

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15, Subpart B of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Canadian ICES Statement:

This digital apparatus does not exceed the Class B limits for radio noise emissions from a digital apparatus as set out in the Radio Interference Regulations of the Canadian Department of Communications. This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique respecte les limites de bruit radioélectrique d'un appareil numérique de classe B prescrites dans le Règlement sur le bruitage radioélectrique du ministère des Communications du Canada. Cet appareil numérique de la Classe B est conforme à la norme NMB-003 du Canada.

Declaration of Conformity

Marking to this symbol

Indicates compliance with the Essential Requirements of the EMC Directive of the European Union (2004/108/EC). This equipment meets the following performance standard:

- EN 60950-1: 2006 + A11: 2009 + A1: 2010 + A12: 2011 (UL 1950 Limited)
- IEC 60950-1: 2005 (2nd Edition) + A1: 2009 (IEC Technical Report/Corrigendum)
- EN 60332-1: 2008, EN 60332-2: 2005, EN 71-3: 2013
- UL 1950-1: 2007 (E12.1), CAN/CSA-C22.2 No. 60950-1-07 + A1: 2011

Additional Certificates issued for specific countries available on request:
Germany: EN 60950-1:2006/EN 60950-1:2009
Italy: EN 60950-1:2006/EN 60950-1:2009
Spain: EN 60950-1:2006/EN 60950-1:2009
France: EN 60950-1:2006/EN 60950-1:2009
UK: EN 60950-1:2006/EN 60950-1:2009
China: GB 4943.1-2005/GB 4943.1-2011
Japan: JIS C 0010/IEC 60950-1:2006
South Korea: KS C 7510/IEC 60950-1:2006
India: IS 13252/IEC 60950-1:2006
China: GB 4943.1-2005/GB 4943.1-2011
China: GB 4943.1-2005/GB 4943.1-2011
China: GB 4943.1-2005/GB 4943.1-2011
China: GB 4943.1-2005/GB 4943.1-2011
China: GB 4943.1-2005/GB 4943.1-2011



This symbol on the product or its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste for recycling, please contact your local authority, or where you purchased your product.

Please visit the following URL for a complete copy of the Declaration of Conformity:
<http://www.turtlebeach.com/homepage>