


# alarmClock Cloud | MUID |

## Overview





Packaging include USB charging cable, Metal patch

# Icon explanation

Temperature



When the battery is less than 20% charged, the charging icon blinks to indicate that it needs to be charged. The icon continuously lights up while charging and extinguishes automatically when fully charged.

# Alarm



The alarm icon lights up when you press the alarm button, you can view the alarm time and it will automatically revert to the time display after 3 seconds. The alarm icon will show when the alarm is set.

# Snooze

When the alarm is on snooze mode, the snooze icon "Zz" stays on.

# Time setting

To set the time press and hold the time button until the hour number blinks, indicating that you can adjust the time

### Features

#### Clock function

The time is displayed in 24-hour format and the time/year/date can be set.

#### Display setting

The display has two modes: long light mode and sleep mode. Long light mode: the alarm clock is always on when the external power supply is powered and the time and temperature display are continuously illuminated.

Sleep mode: When the product is powered by its internal battery, the product enters sleep mode after being left for 5 seconds. You can tap the product or make a sound to wake up the display light again.

#### Snooze function

When the alarm goes off, you can turn on the snooze function by gently shaking the clock. The snooze reminder icon "Zz" will also light up when the snooze function is turned on. The alarm will go off again 5 minutes after the snooze function is turned on. After 3 minutes of continuous alarm sound without touching it, the alarm clock will turn off the alarm for the day, or you can directly press the alarm switch to turn it off.

## DesignNest vision

DesignNest is a one-stop platform for designers to launch their products worldwide, for retailers to order innovative products for their stores and for consumers to afford these designs from authentic designers.

Make product design affordable for everyone.

Creating an end-to-end platform for funding, engineering, manufacturing, marketing, sales and fighting copycats - serving designers, retailers and consumers.

# Function key explanation



On

Alarm button Single press to view the alarm, long press to set the alarm

**Alarm slider** ON: turn the alarm on. OFF: turn the alarm off.

#### Time button Single press to view the date, long press to adjust time, year, month and day.



Plus/minus buttons When setting the time and alarm, you can press the plus/minus buttons to adjust the numbers on the display.

Single press the plus/minus buttons: You can adjust the brightness of the display light.

## **Technical specs**

Product Name	alarm Clock Cloud
Patent	ZL201430170050.5
Material	PC, ABS
Dimension	122mmX79mmX35mm
Weight	120g
Power Input	DC 5V/1A
Battery	900mAh
Color	Pink/Green

# Instructions for use

#### Time/date/year setting

Long press the time button O until the time setting lights up to enter the time adjustment. The clock time blinks, press O/O to adjust the hour clock numbers, single press the time button O to enter the minute adjustment, the minute numbers on the screen blink, press O/O to adjust the minute numbers. Press the time button again to confirm the completion of time setting, the year, month and day can be adjusted in turn.

#### Alarm setting

Long press the alarm clock button until the O lights up and the alarm hour number blinks to enter the alarm setting, press O/O to adjust the alarm time. Press the alarm button again to enter the minute adjustment, the minute number blinks, press O/O to adjust the minutes. Press the alarm button again to confirm the alarm setting.

# Safety Precautions

1. Do not attempt to disassemble, repair or modify this product by yourself.

2. Do not wet the clock or operate with wet hands.

3. Do not put the clock in a place with high temperature or high humidity.

4. Severe vibration or impact should be prevented to avoid damage.

5. Avoid water or other liquids to flow into the product, causing damage.

6. Do not place the clock on a slanted or unstable surface to avoid sliding damage.

7. During the use of the clock, if an abnormal situation occurs, please stop using it.

8. The product does not include a USB power source, please be sure to use one from a known manufacturer.

