



RAZER STREAM CONTROLLER

MASTER GUIDE


Whether you're a streamer or content creator, let your creativity flow with the **Razer Stream Controller**. Instantly access any function through its customizable touchscreen, buttons, and dials. Create shortcuts and multi-task with ease so you can focus on engaging the fans and growing your following.

CONTENTS

1. WHAT'S INSIDE.....	3
2. WHAT'S NEEDED	4
3. TECHNICAL SPECIFICATIONS	4
4. LET'S GET YOU COVERED	5
5. GETTING STARTED.....	6
6. USING THE CONTROLLER	7
7. CONFIGURING THE RAZER STREAM CONTROLLER VIA RAZER SYNAPSE	9
8. SAFETY AND MAINTENANCE	16
9. LEGALESE.....	17


1. WHAT'S INSIDE

- Razer Stream Controller




- A. Type C port
- B. 6 Tactile analog dials
- C. Dial information panels
- D. 12 Haptic Switchblade keys
- E. Home button
- F. Workspace buttons 1-7

- Type C to Type A cable



- Detachable stand



- Important Product Information Guide

2. WHAT'S NEEDED

PRODUCT REQUIREMENTS

- Direct Type A connection to a PC

RAZER SYNAPSE REQUIREMENTS

- Windows®10 64-bit (or higher)
- Internet connection for software installation

LOUPEDECK SOFTWARE 5.0 REQUIREMENTS


- macOS® X 10.14 / Windows®10 64-bit (or higher)
- Internet connection for software installation

3. TECHNICAL SPECIFICATIONS

- Interface:
 - 12 Haptic Switchblade keys
 - 6 Tactile analog dials with 2 Side LCD screen
 - 8 Programmable buttons
- Connectivity: 2-meter Type A to Type C cable
- Stand: Detachable stand
- Size: 151 mm (Length) x 101.5 mm (Width) x 30.2 mm (Height)
- Weight: 210 g (Stream Controller only), 216 g (Including detachable stand)
- System requirements:
 - macOS X 10.14 (and later)
 - Windows 10 systems
 - Loupedeck Software

4. LET'S GET YOU COVERED


You've got a great device in your hands, complete with a 1-year limited warranty coverage. Now maximize its potential and score exclusive Razer benefits by registering at razerid.razer.com



Got a question? Ask the Razer Support Team at support.razer.com

5. GETTING STARTED

1. Connect the Razer Stream Controller to your computer.




2. Install Razer Synapse when prompted or download the installer from razer.com/synapse
i (For macOS systems) Download the Loupedeck Software from loupedeck.com/get-started.
3. Use the Razer Synapse app to access the Loupedeck Software and create content with any of the controller's natively integrated programs or customize its dials and buttons to adapt it to your workflow.
i The Loupedeck Software is required when using the controller and any of its features.

6. USING THE CONTROLLER

UNDERSTANDING CONTROL ELEMENTS

The Razer Stream Controller is divided into two elements that allow you to seamlessly move between your tools and applications.



Workspaces

A workspace is a toolbox or collection of related functions. On the Razer Stream Controller, you can switch between various workspaces (or toolboxes) efficiently using the Workspace buttons 1-7, allowing you to perform your most needed actions across applications. [Learn more about workspaces](#)

General elements

Comprised of the home and customizable workspace buttons, use these buttons to access preferred functions or workspaces across various applications quickly.

- **Home button.** Return or go back to your home workspace.
- **Workspace buttons 1-7.** Fully customizable and remain constant even as you switch between apps. [Learn more about the workspace buttons](#)

Workspace elements

Controlled by workspaces, the functions of the tactile analog dials and haptic Switchblade keys change based on the current workspace.



- **Tactile analog dials.** Control variable values (e.g., brightness sliders, volume level, media track scrolling, etc.) with a press function that can reset values, toggle other settings, or do a preferred action. [Learn more about dials](#)

- **Dial information panels.** Displays the current function or value of its corresponding analog dial.
- **Haptic Switchblade keys.** Activate different functions (e.g., open tools, presets, control media, launch apps, etc.) within every workspace. You can set multiple pages for each Switchblade key that you can access by swiping left or right on the Switchblade page.

These keys are colored to indicate their function. [Learn more about color codes](#)

USING THE DETACHABLE STAND

For an inclined setup, insert the controller into the hooks of the stand and firmly press on each hook until the controller locks in place. To detach, gently unlatch each hook from the controller.



7. CONFIGURING THE RAZER STREAM CONTROLLER VIA RAZER SYNAPSE


i *Internet connection is required for installation, updates, and cloud-based features. Registering for a Razer ID account is recommended but optional. All listed features are subject to change based on the current software version, the connected device(s), and supported apps and software.*

SYNAPSE TAB

The Synapse tab is your default tab when you first launch Razer Synapse. This tab allows you to navigate the Dashboard subtab.


Dashboard

The Dashboard subtab is an overview of your Razer Synapse, where you can access all your Razer devices, modules, and online services.



Modules


The Modules subtab displays all installed and available modules for installation.



Global Shortcuts


Bind operations or Razer Synapse functions to custom key-combinations from any Razer Synapse-enabled device inputs, which apply across all device profiles.

 *Only Razer Synapse-enabled device inputs will be recognized.*



STREAMING TAB

Use the Streaming tab to launch or download the Loupedeck Software and change the controller's application profile using Razer Synapse.



Profile

On the Razer Stream Controller app, a profile is a pre-configured workspace designed to make the controller immediately usable and compatible with the supported application that you're using.

! *The Loupedeck Software is required for Razer Synapse to take control of the Razer Stream Controller's profiles. It's also necessary that Dynamic Mode is turned OFF on the Loupedeck Software for the Razer Synapse app to have control over the controller's profiles.*

Quick Tips


- Visit [Loupedeck Software](#) for a detailed understanding of the Loupedeck Software and its features.
- Understand how each plugin works for application-specific profiles at [Loupedeck Plugin Guides](#).

PROFILES TAB

The Profiles tab is a convenient way to manage all your profiles and link them to your games and applications.


Devices

View which games are linked to each device's profiles or which Chroma Effect is linked to specific games using the Devices subtab.



Linked Games


The Linked Games subtab allows you to add games, view devices linked to games, or search for added games. You can also sort games based on alphabetical order, last played, or most played. Added games will still be listed here, even if they are not linked to a Razer device.



To link games to connected Razer devices or Chroma Effects, simply click on any game from the list, and then click **Select a device and its profile to launch automatically during gameplay** to select the Razer device or Chroma Effect it will link with. Once connected, you may click the Miscellaneous button (●●●) of the corresponding Chroma Effect or device to select a specific Chroma Effect or profile.

SETTINGS WINDOW

The Settings window, accessible by clicking the (⚙) button on Razer Synapse, enables you to configure the startup behavior and display language of Razer Synapse, view the master guides of each connected Razer device, or perform a factory reset on any connected Razer device.



General tab

The General tab lets you change the software's display language, startup behavior, theme, and on-screen notifications display. You may also manually sync your profiles to the cloud (↻) or view the master guide of all connected Razer devices and installed modules.

Reset tab

The Reset tab allows you to perform a factory reset on all connected Razer devices with on-board memory and/or reset Razer Synapse tutorials to acquaint yourself again with Razer Synapse's new features on its next launch.



All profiles stored on the selected device's on-board memory will be erased when you reset a Razer device.

About tab

The About tab displays brief software information and copyright statement, and provides relevant links for its terms of use. You may also use this tab to check for software updates, or as quick access to Razer's social communities.

8. SAFETY AND MAINTENANCE

SAFETY GUIDELINES

To achieve maximum safety while using the Razer Stream Controller, we suggest that you adopt the following guidelines:

Should you have trouble operating the device properly and troubleshooting does not work, unplug the device and contact the Razer hotline or go to support.razer.com for support.

Don't take apart the device, and don't attempt to operate it under abnormal current loads. Doing so will void your warranty.

Don't use or install the device near water, moisture, solvents, or other wet surfaces; expose it to high temperatures or direct sunlight for an extended period of time, or get moisture or liquid inside the device.

Maintain a minimum distance of at least 15 cm (6 in) between implanted medical devices and the device to reduce the risk of interference.

Keep the device and its components away from liquid, humidity, or moisture. Operate the device only within the specific temperature range of 15°C (59°F) to 35°C (95°F). Should the temperature exceed this range, unplug the device to let the temperature stabilize to an optimal level.

MAINTENANCE AND USE

The Razer Stream Controller requires minimum maintenance to keep it in optimum condition. Once a month, we recommend you clean it using a soft cloth or cotton swab to prevent dirt buildup. Do not use soap or harsh cleaning agents.

9. LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2022 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, and “For Gamers. By Gamers.” are trademarks or registered trademarks of Razer Inc. and/or affiliated companies in the United States and other countries. Actual product may differ from pictures. All other trademarks are the property of their respective owners. Warranty not valid outside of product’s intended region.

©2022 LoupeDeck Ltd. All rights reserved.

macOS is a trademark of Apple Inc., registered in the U.S. and other countries and regions.

Windows and the Windows logo are trademarks of the Microsoft group of companies.

Razer Inc. (“Razer”) may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent or other intellectual property right. The Razer Stream Controller (the “Product”) may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY

For the latest and current terms of the Limited Product Warranty, please visit [razer.com/warranty](https://www.razer.com/warranty).

LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer’s liability exceed the retail purchase price of the Product.

GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.