


Product Manual



Jennifer

EN

USER MANUAL



1. Long press "⓪" ① for 2 seconds to turn on or off the vibration
2. Short press "Ⓜ" ② to switch among 25 vibration modes
3. Short press "Ⓜ" ③ to switch among 5 vibration modes
4. Insert the cable line into "Dc" for charging. The light will blink during charging, and will then light up continuously when it is fully charged

SPECIFICATION

Material:	Silicone+ABS
Size:	230x50mm
Mode:	25 Mode vibration
Charge time:	120-180 Mins
Using time:	90-120 Mins
Waterproof:	IPX6

EN

PRODUCT DESCRIPTION

The design of appearance is novel & simple & elegant. The design with strong vibration but the handle does not vibrate when used, which can massage the body more comfortably.

SAFETY

1. Don't share it with others for your health.
2. Stop using it if you feel uncomfortable.
3. Stop using it if you find the head of the product is not smooth enough or broken.
4. Keep it from children's reach.

CLEANING AND STORAGE


1. Please clean it thoroughly before and after using.
2. Warm water and medicinal alcohol can be used to clean this product, but warm water is highly recommended.
3. Naturally air dry and avoid direct sunlight.
4. Store it in a dust-free place.

ATTENTION

1. Please charge it before using, don't use it while charging.
2. Don't use it around our face, throat, chest or an open wound.
3. Once the battery has been fully charged, unplug the toy's DC plug.

NL

USER MANUAL



GEbruIKSAANWIJZING:

1. Houd "⓪" 2 seconden lang ingedrukt om de trilling in of uit te schakelen.
2. Druk kort op "Ⓜ" om te schakelen tussen 25 vibratiemodus.
3. Druk kort op "Ⓜ" om tussen 5 vibratiestanden te schakelen.
4. Steek de kabellijn in "Dc" om op te laden, het lampje knippert tijdens het opladen en brandt vervolgens continu wanneer het volledig is opgeladen.

SPECIFICATIE

Materiaal:	siliconen+ABS
Maat:	230x50mm
Modus:	25 Modus Trillingen
Oplaadtijd:	120-180 minuten
Gebruikstijd:	90-120 minuten
Waterdicht:	IPX6

NL

PRODUCTOMSCHRIJVING

1. Alles is gemaakt van vloeibare siliconen die zachter en veiliger in gebruik is.
2. Draadloze afstandsbediening maakt ook gebruik van plastic coatingtechnologie. Het is waterdicht, geschikt voor badkamer, badkuip en andere prive-wateromgevingen.

VEILIGHEID

1. Deel het niet met anderen voor uw gezondheid.
2. Stop met het gebruik ervan als u zich ongemakkelijk voelt.
3. Stop met het gebruik als u vindt dat de kop van het product niet glad genoeg of gebroken is.
4. Houd het buiten het bereik van kinderen.

REINIGING EN OPSLAG

1. Reinig het grondig voor en na gebruik.
2. Warm water en medicinale alcohol kunnen worden gebruikt om dit product te reinigen, maar warm water wordt ten zeerste aanbevolen.
3. Gelieve natuurlijk aan de lucht te drogen en direct zonlicht te vermijden.
4. Bewaar het op een stofvrije plaats.

AANDACHT

1. Laad het alstublieft op voordat u het gebruikt!
2. Gebruik persoonlijk glijmiddel van goede kwaliteit. Iets (massageolie, handcreme of reinigingsoplossing etc.) dat gevaarlijke stoffen bevat, kan niet als smeermiddel worden gebruikt.
3. Zodra de batterij volledig is opgeladen, koppelt u de stroomstekker van het speelgoed los.



**BLOOSY
LOVE**

CE O xt 
MADE IN CHINA