



Rotating LED Disco Lamp

USER'S MANUAL

Remote controller buttons



Buttons explanations

Mode	Effect	Content
A1	AUTO	Blue light turns on
A2		Green light turns on
A3		Red light turns on
A4		Red-Green-Blue mode 1
A5		Red-Green-Blue mode 2
A6		Red-Green-Blue mode 3
MUSIC 1	SOUND	Light on with sound,color changes to sound
MUSIC 2		Auto sound
MUSIC 3		Light off without sound

Note: Please remove the plastic protector at the bottom of the remote before use. Please aim the remote controller towards the IR signal receiver without barriers. Please allow for a 1 second delay when switching to other lighting parrents. The remote control can be used within 5 meters distance of the lamp.

WARNING: Please read this manual carefully before using this product.