


Product Manual



Nicole

EN

USER MANUAL



1. Long press "Ⓚ" ① to power on and then come into standby mode.
2. When it is in standby mode, short press "Ⓜ" ② to control the big motor to vibrate.
3. In any mode, long press "Ⓚ" ① to power off.
4. The charging cable should be plugged into the charging hole at "Dc", which is at the end of massager to charge.

SPECIFICATION

Material:	Silicone+ABS
Size:	202x37mm
Mode:	7 Mode Vibration
Charge time:	120Mins
Using time:	90Mins
Waterproof:	IPX5

EN

PRODUCT DESCRIPTION

1. 7 modes of vibration
2. Made of safe silicone, soft and comfortable
3. Quiet design, protecting your privacy
4. Offer fabulous orgasms for peak sexual wellness

SAFETY

1. Don't share it with others for your health.
2. Stop using it if you feel uncomfortable.
3. Avoid serious injury when it is used to stimulate the clitoris, use it with sex lubricant that is recommended.
4. Stop using it if you find the head of the product is not smooth enough or broken
5. Keep it from children's reach.

CLEANING AND STORAGE


1. Please clean it thoroughly before and after using.
2. Warm water and medicinal alcohol can be used to clean this product, but warm water is highly recommended.
3. Naturally air dry and avoid direct sunlight.
4. Store it in a dust-free place.

ATTENTION

1. Please charge it before using.
2. Please use good quality personal lubricant. Something (Massage oil, hand cream or cleaning solution etc.) containing hazardous substances cannot be used as lubricant.

NL

USER MANUAL



GEBRUIKSAANWIJZING:

1. Druk 2 seconde op ① tot het in standby modus komt.
2. In standby modus, druk kort op "Ⓜ" ② om vibratie functie aan te zetten. Korte druk op "Ⓜ" ② kan je veranderen van vibraties (7-vibratie modus totaal)
3. Druk 2 seconde op ① om uit te schakelen.
4. De oplaadkabel moet worden aangesloten in het oplaadgat bij "DC", dat aan het einde van de stimulator is gevestigd.

SPECIFICATIES

Materiaal:	Vloeibare siliconen
Maat:	202X37mm
Modus:	7-vibratie standen
Oplaadtijd:	120 minuten
Gebruikstijd:	90 minuten
Waterdichtheid:	IPX5

NL

PRODUCTOMSCHRIJVING

1. 7-vibratie standen.
2. Gemaakt van veilige siliconen, zacht en comfortabel.
3. Stille design voor meer privacy en genot.
4. Bied fantastische orgasmes voor een optimaal seksueel welzijn

VEILIGHEID

1. Deel het niet met anderen voor uw gezondheid.
2. Stop met het gebruik ervan als u zich ongemakkelijk voelt.
3. Vermijd letsel wanneer het wordt gebruikt om de clitoris te stimuleren, gebruik het met seksmiddel dat wordt aanbevolen.
4. Stop met het gebruik als u vindt dat de kop van het product niet glad genoeg of gebroken is.
5. Houd het buiten het bereik van kinderen.

REINIGING EN OPSLAG

1. Reinig het grondig voor en na gebruik.
2. Warm water en medicinale alcohol kunnen worden gebruikt om dit product te reinigen, maar warm water wordt ten eerste aanbevolen.
3. Gelieve natuurlijk aan de lucht te drogen en direct zonlicht te vermijden.
4. Bewaar het op een stofvrije plaats.

AANDACHT

1. Laadt het op voordat u het gebruikt!
2. Gebruik persoonlijk glijmiddel van goede kwaliteit. Iets (massageolie, handcrème of reinigingsoplossing etc.) dat gevaarlijke stoffen bevat, kan niet als smeermiddel worden gebruikt.



**BLOOSY
LOVE**

CE O_{xt} 
MADE IN CHINA