





Déko-Play schommelzitjes gebruiksaanwijzing




Voor een speeltoestel met een balkhoogte van 2,5m.



150100



150601




150684

 150681 150682 150683




150150





150312

 150314




RVS ketting

150216




150210



- 150322 met inlegkussen
- 150324 met inlegkussen
- 150331 met inlegkussen en met verstelbare touwen
- 150334 met inlegkussen en met verstelbare touwen



RVS beslag





150215



150903

 150901 150902 150904



150802

 150801



150671

 150674

