

# S69 Wired Mechanical Keyboard



### Win system key combination

Multimedia function keys must be pressed with the FN+CTRL key combination (Ice blue light appears underneath the FN button to use the multimedia function keys)

multimedia function	functionality	
FN+ 1	concert	
FN+2	calculators	
FN+ 3	WIN+TAB	
FN+4	WIN+E	
FN+ 5	Keyboard backlighting -	
FN+ 6	Keyboard backlighting +	
FN+7	previous song	
FN+ 8	Play/Pause	

multimedia function	functionality
FN+9	next song
FN+0	unmute
FN+ -	Volume-
FN+=	Volume +
FN+ WIN	Lock WIN/Unlock WIN

#### F1~F12 function keys

function key	functionality	
FN+1	F1	
FN+ 2	F2	
FN+3	F3	
FN+4	F4	
FN+ 5	F5	
FN+ 6	F6	
FN+ 7	F7	
FN+ 8	F8	

function key	functionality
FN+ 9	F9
FN+ 0	F10
FN+ -	F11
FN+=	F12

## iOS key combination

Multimedia Function Keys

multimedia function	functionality	multimedia function	functionality
FN+1	Screen brightness -	FN+ 7	previous song
FN+2	Screen brightness +	FN+ 8	Play/Pause
FN+3	split-screen	FN+9	next song
FN+4	Call up Siri.	FN+0	unmute
FN+ 5	Keyboard backlighting -	FN+ -	Volume-
FN+ 6	Keyboard backlighting +	FN+=	Volume+

F1~F12 keys have to be pressed FN+Ctrl key combination (F1~F12 function keys can only be used if the ice blue light appears under the FN button))

function key	functionality	function key	functionality
FN+1	F1	FN+ 9	F9
FN+2	F2	FN+ 0	F10
FN+3	F3	FN+ -	F11
FN+4	F4	FN+=	F12
FN+ 5	F5		
FN+ 6	F6		
FN+7	F7		
FN+8	F8		

## Win/iOS universal key

common key	functionality	common key	functionality
FN+INS	Switching light effects	ESC	Single press default function
FN+方向键上下	Adjusts backlight brightness by 5 levels	FN+ESC	lt's "·"
FN+方向键左右	Adjusts dynamic backlighting speed by 5 levels	FN+Shift+ESC	lt's "~"
FN+O	pause		
FN+I	Scroll Lock		
FN+K	Home		
FN+L	Eed		
FN+U	Prtsc		