REMOTE CONTROL ANALYSIS



Surround flight/ GPS switch (long press for 3 seconds)

Throttle (left) joystick / three speed switching (press down)

Headless mode (long press for 3 seconds) / return to home Start (unlock)



Antenna

Camera down

Geomagnetic calibration

Joystick to (right)

One key up/down (long press for 3 seconds)

Take photo/video (long press for 3 seconds) Switch

Phone clip