

Product Manual

Please read the product manual in detail before using
Hand-held Electric Cleaning Brush

Safety Instructions

- ❖ This product is electric cleaning products, do not use as toys, please refer to the following operating instructions
- ❖ Stay away from flammable and explosive substances at any time
- ❖ Before use, please check whether the brush is securely installed, do not shake the product vigorously .
- ❖ Wear eye shields and gloves when used in conjunction with irritating substances.
- ❖ Do not insert any accessories while the machine is in operation.
- ❖ Cannot be soaked in water
- ❖ In any case, do not attempt to remove the battery. If the product housing is broken, should stop using and charging.
- ❖ When charging, keep away from heat, oil , flammable and explosive substances.
- ❖ This product can only be charged with a dedicated adapter.
- ❖ The adapter can only be applied in standard power and should be aware that the power supply corresponds to the adapter voltage.
- ❖ Please do not disassemble the adapter by yourself

Product Parameter


Adaptor	Power	Rotational Speed	Handle Length	Battery Capacity	Working Time	Charging Time
DC 5V 600mA	About 10W	About 300RPM	About 84cm	3.7V 2600mA	1H	2.5H

Function Information

This product is a hand-held electric cleaning brush, mainly used for the cleaning of the surface, the working principle is to use the motor to drive the brush rotation, to achieve the effect of surface cleaning.

Main Feature

- brush easy to dismounting, patents with utility models.
- Various brush to meet different requirements.
- Hand-held position is soft silicone material, durable, environmentally friendly, comfortable feel.
- Built-in power supply for rechargeable use.
- Low voltage operation to make the product safer.
- Easy to operate and convenient for consumers to use.



1. Power Switch
2. Indicator Lamp
3. Extension rod socket
4. Charge Port

What's in the Box



Flat brush*1



Arc brush*1



Pointy brush*1



Velcro holder*1



Scouring Pad*1



Towel cloth*1



Sponge*1



Main body*1



extension rod*1



JSB charging line*1



Product Manual*1



Banister brush



Polijsborstel



kleine spons



kleine doek

How to use


Working mode

- ◆ Press power switch once to turn on ,light on.
- ◆ Press power switch twice to turn off,light off.
- ◆ Constant flashing lights indicate low power.
- ◆ The indicator light appears breathing effect when charging.
- ◆ Indicator lamp constant light when fully charged.


Assembling methods

Select the appropriate brush according to the cleaning requirements,

Note: Make sure the brush is securely installed



Charging: Unplug the silicone Plug and insert the DC plug into the DC hole.



Telescopic link Mounting: Unplug the silicone plug and rotate the threaded end of the telescopic link into the hole .When the telescopic rod is unfastened from the main engine, the movable plate on the telescopic rod should be lifted first.

Note: Before the telescopic rod connection is used, make sure that the telescopic rod and host are not loosened.

