SILVERGEAR

UNDERBLANKET WITH DUO-ZONE CONTROL

CONTROL UPPER BODY AND FOOT TEMPERATURE

NL: Verwarmde Onderdeken met Duo-Zone Control | DE: Wärmeunterbett mit Zwei-Zonen-Steuerung
FR: Sous-couverture avec contrôle de deux zones



Please read this instruction manual carefully before use and keep it for future reference.

IMPORTANT INFORMATION!
RETAIN FOR FUTURE USE!

Read the instruction manual carefully before using this device, especially the safety instructions, and keep the instruction manual for future use.
Should you give this device to another person, it is vital that you also pass on these instructions for use.

Not suitable for children under 3 years.

Do not puncture the heated cushion!

Do not use folded or rucked

Do not tumble dry

Do not dry clean

Do not iron

Do not bleach

Machine wash

IMPORTANT SAFETY INSTRUCTION

1. Check the blanket carefully before each use.
2. If you notice visible damage on the blanket, do not use and return to the manufacturer or dealer.
3. If the supply cord of this appliance is damaged, it must only be replaced by the manufacturer, its service agent or similarly qualified person in order to avoid a hazard.
4. The appliance must be returned to the manufacturer or his agent if the link has ruptured.
5. Examine the blanket frequently to check that there are no signs of wear or damage. If there are such signs, if the appliance has been misused or does not work, return it to the supplier before switching it on again.
6. The blanket can only be operated with detachable controller SS19.
7. Before connecting the blanket to the power supply, please ensure that the supply voltage stated on the rating plate is compatible with your mains supply.
8. The blanket may not be operated while folded, creased, wrapped in a cover or placed around the mattress.
9. Four fastening straps are located on the corner of the blanket. Use these straps to attach the blanket to the mattress using a suitable band or cord. Make sure that the blanket is firmly strapped to the mattress in both directions and that it will not crease while it is being used. Check if it is in the correct position before lying on it.
10. The appliance should not be used on an adjustable bed.If the appliance is used on an adjustable bed, check that the blanket and cord do not become trapped or rucked, for example in hinges.
11. Place the blanket on mattress with the mains lead at the pillow end. Ensure the controller emerges from the top side of the blanket and that heating elements do not emerge under the pillow area.

12. Children under the age of three are not to use this appliance due to their inability to react to overheating.This appliance must not be used by persons insensitive to heat and other very vulnerable persons who are unable to react to overheating.
13. The appliance can be used by children older than 3 years and younger than 8 years under supervision and with the control always set to minimum temperature value.
14. This appliance can be use by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazard involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
15. Neither pierce the blanket with, nor attach safety pins or other spiky or sharp objects to the pad.
16. if the appliance is slept on with the controls set to a higher temperature the user may suffer skin burns or heat stroke.For prolonged use, it is recommended that the temperature be set to "1".
17. People with pacemakers should consult their physicians or the manufacturer of the pacemaker before using the blanket, as the electronic and magnetic emission from this product can affect the pacemaker’s function under certain circumstance.
18. do not use if wet.
19. This appliance is not intended for medical use in hospitals.
20. The cable and control unit of the appliance can give rise to risks of entanglement, strangulation, tripping or treading if not correctly arranged. The user shall make sure that excess ties and electric cords shall be arranged in a safe way.
21. Keep the mains cable away from hot surfaces.

OPERATION

1. Please plug in the power cord, all the LED display is fully on for 1 second for self-test, and then off, the heater does not heat, enter the standby mode.
2. Please long press the on/off button" " to turn on the blanket, and enter the default mode. The default mode is to heat the upper and lower body in 3 gears for 1 hour. At this time, the upper digital tube shows 3, indicating that the current upper body heating gear is 3, the lower digital tube shows 3, indicating that the current lower body heating gear is 3; The timer 1h icon is lit.
3. You will feel the electric blanket starts heating up in a few minutes. If you need a higher heat feeling, please short press button " "or" " to adjust the temperature of upper body and foot part, and the temperature starts cycling from 3-4-5-6-5-4-3-2-1-0-1-2-3-4-5-6, it has 6 heat settings in total. And long-pressing the button " "or" ", you could rapid continuous adjustment the temperature.
4. To adjust the time settings, short press the on/off button" ", the timer is cycled regularly by 1h-3h-9h-1h, and the timer is displayed as a countdown.
5. To turn off the blanket, you still need long press the on/off button" ", and the screen turns blank to stop working.



CLEANING AND MAINTENANCE

- Before cleaning the blanket, unplug it from the mains outletand let it cool down completely or for at least ten minutes.
- The blanket is equipped with a detachable cable. Disconnect the plug and remove the cable from the blanket.
- You may wash the blanket gently by hand. The best way todo this is to put the blanket in a bath with lukewarm water and some mild detergent and then gently squeeze it out.
- Do not use hair dryer to dry this product, have to drynaturally, stretch the blanket out on a flat surface.
- Rinse the blanket several times to remove all the detergent.
- Store the blanket in a clean and dry place, laid out flat withnothing covering or resting on top of it.
- Only use the blanket once it is completely dry.
- You may also wash the blanket in a washing machine at a maximum temperature of 30ºC with low mechanical action and spin. It's advisable to wash it by hand in order to prolongthe life of the product.

STORAGE

When not in use, store the blanket as follows :

- When storing the appliance, allow it to cool down before folding, then gently fold the blanket and place back into the packing bag it arrived in.
- Do not crease the appliance by placing items on top of it during storage.
- Make sure the blanket is dry before folding and packing it away. The blanket should be hung in a ventilated location to dry naturally.
- Do not use mothproofing agents on the blanket.
- The blanket should be store in a cool dry place.

DISPOSAL

This product must not be disposed of together withdomestic waste.
All users are obliged to hand in all electrical or electronic devices, regardless of whether or not they
contain toxic substances, at a municipal or commercialcollection point so that they can be disposed of in an environmentally acceptable manner.
Consult your local authority or your supplier for informationabout disposal.

The CE marking is a certification mark that indicates conformity with health, safety and environmental protection standards for products sold within the European Union. The CE marking is the manufacturer's declaration that the product meets the requirements of the applicable EC directives.

The crossed out wheelie bin symbol means that this product shall not be disposed of with normal household waste. Electronic and Electrical Equipment not included in the selective sorting process are potentially dangerous for the environment and human health due to the presence of hazardous substances. Please dispose of responsibly at an approved waste or recycling facility.

Recycling helps to reduce the consumption of resources and reduce the environmental impact. If you wish to discard the packaging, comply to the environmental legislation in your country.

Warning:Children should not use this underblanket. Close supervision is necessary when the underblanket is used near children. Children should be supervised to make sure that they do not play with the underblanket. Never place a baby on an electric blanket - they can dehydrate and get burns at fairly low temperatures.

Warning: This underblanket is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the underblanket by a person responsible for their safety. Never use an electric blanket when it's wet or the occupant of the bed is wet. People with incontinence should not use electric blankets.

This blanket must be kept in the fully spread condition at all times during use to avoid overheating. It is imperative that the blanket is frequently inspected to ensure that this condition is being maintained.

Bed clothes should not be folded back when the blanket is switched on.

Do not leave heavy objects on the bed when the unit is switched on.

Never tuck an electric blanket under the mattress, never fold it over double, crease it, or extend it under the pillows.

Long periods of use at the high setting can result in skin irritation or burns.

Be sure that this blanket is used only on an alternating current supply circuit of the correct voltage.

The power supply and switch must, as for as practicable, be kept outside the bed.

Switch off the power and remove the plug when this blanket is not in actual use.

Always use the electric blanket as an under blanket unless it is specifically designed for use as an over-blanket.

Never use an electric blanket with a waterbed.

Never use pins – they can damage the blanket's wiring.

Itemnumber:4698
Batchnumber:24833
Eancode: 8711568105442

220-240V
50HZ

RECICLA
Al Azul

22
PAP
Paper
Carta
Manual
Manuale

FR

Raccolta carta
Verifica le disposizioni
del tuo comune

KARSTEN
INTERNATIONAL

Karsten International B.V.
Overschiestraat 63
1062 XD Amsterdam
The Netherlands
info@karsten.nl

Made in China