




**Lees de gebruiksaanwijzing goed door!**  
**Read the user-manual carefully!**

## Waarschuwing!

- \* Houd uit de buurt van vuur" of blootstelling aan hoge temperaturen en plaats het niet op een donkere, vochtige plaats.
- \* Vervang of repareer tijdig beschadigde onderdelen.
- \* Gebruik de zindelijkheidstrainer niet als deze beschadigd of gebroken is.
- \* Controleer altijd of alle onderdelen van de zindelijkheidstrainer goed werken.
- \* Verplaats de zindelijkheidstrainer niet wanneer het kind erop zit.
- \* Controleer voor gebruik of er geen deel van het lichaam van uw kind vastzit in het bewegende deel van de zindelijkheidstrainer.
- \* Het is verboden om het te gebruiken bij het zwembad, op ruige en gevaarlijke plaatsen.
- \* Het is verboden om het kind op de plaat te zetten.
- \* Laat uw kind niet alleen achter zonder toezicht om gevaar te vermijden.
- \* Controleer voor gebruik of alle onderdelen van de zindelijkheidstrainer zijn vastgezet.
- \* Het maximale gewicht van deze zindelijkheidstrainer is 20 kg.
- \* Kinderen jonger dan 6 maanden mogen dit product niet gebruiken.
- \* Lees deze handleiding zorgvuldig door en bewaar deze voor toekomstige referentie.

## INSTRUCTIE VOOR MONTAGE EN GEBRUIK












### Miyoni® Toilet Trainer




### Miyoni® Toilet Trainer




Made in P.R.C

①	②	③	④	⑤	⑥	⑦	⑧	⑨	⑩	⑪
										
1	1	1	2	2	4	4	1	8	8	1




Step1:




Step2:




Step3:



Step4:



Step5:




## Warning!

- \* keep away from fire" or expose to high temperatures, and do not place it in a dark, damp place.
- \* Please replace or repair damaged parts in time.
- \* Do not use if the potty trainer is damaged or broken.
- \* Always check that all parts of the potty trainer are working properly.
- \* When the child is sitting in the potty trainer, please do not move it at will.
- \* Before use, make sure that no part of your child's body is stuck in the movable part of the potty trainer.
- \* It is forbidden to use at the pool, in rugged and dangerous places.
- \* It is forbidden to put the child on the plate.
- \* Do not leave your child alone in the absence of care to avoid danger.
- \* Before use, please make sure that all parts of the potty trainer are fixed.
- \* The maximum weight of this potty trainer is 20 kg.
- \* It is forbidden for children under 6 months.
- \* Please read this manual carefully and keep it for future reference.

## INSTRUCTION FOR ASSEMBLY AND USE












### Miyoni® POTTY TRAINER




### Miyoni® Toilet Trainer




Made in P.R.C


①	②	③	④	⑤	⑥	⑦	⑧	⑨	⑩	⑪
										
1	1	1	2	2	4	4	1	8	8	1




Step1:




Step2:



Step3:



Step4:



Step5:

