Wake Up Light



User Manual

Please read the user manual carefully before using the device

Specifications

Product name: Wake Up Light

Adapter input: 100-240V~50/60Hz 0.2A

2

Adapter output: 5V=1A

Wake up light input: DC5V=1A

Lighting power: 3W

Operating temperature: -10℃—50℃


Product net weight: 288g

Product size: $\Phi 106 \times 151 \, \text{mm}$

Key Icon Definition

	Т	Sleep lamp timer key (Tap for timer: turn off the lamp at 10, 30, 60 minutes.)		
	(Clock set key	Ø	Alarm clock set key
	+	Time and alarm clock adjustment increase Alarm volume increase		
	_	Time and alarm clock adjustment decrease		

Button Explanation



3




Display Function Explanation



Power Connection (ON/OFF)

This machine without built-in battery.
When using the machine, please use the standard power adapter which included in the accessories, the power is turned on when they connected.



5 6 7

Clock Setting

Short press the clock setting button "

" to activate clock settings.

Press "+" and "-" keys to select 12H or 24H. Confirm the

setting by short press the key " $_{\ominus}$ ". Press "+" and "-" keys to choose the hours setting. Confirm the hours setting by short press the key "G", then press "+" and "-" keys to set the minutes setting. Confirm the minutes setting by short press the key "0". (In 12H mode, match the corresponding "AM" and "PM" time period when setting the clock)

Wake Up Light Alarm Clock Setting

Hold down the alarm clock key "" to activate the alarm clock settings, the display will flash the hours or minutes digital symbol. Adjust alarm time with use of "+" and "-" keys, then press the key "" to confirm. After setting the alarm time, it enters the selection for alarm sound directly. It has 7 options. Click the "+", "-" button to select the favorite options. Options 1-5 are the mode with the alarm ring and sunrise simulation wake up light, option 6 only with alarm ring and no sunrise simulation wake up light mode, option 7 only with sunrise simulation wake up light and no alarm ring mode, after selecting, press "" to complete the setting. The alarm icon "" is appeared on the screen and the alarm setting is completed and ready. If you want to turn off the alarm clock. completed and ready. If you want to turn off the alarm clock, please press the alarm clock key "".

Alarm clock volume setting: Click or long press the "+" "-" key to adjust the volume of the alarm ringtone under normal

When the alarm sounds, you can touch the top touch key or press any keys to stop the alarm.

Sunrise Wake Up Light Alarm Clock Use

Enjoy the morning waking up in "sunrise" and nature sound. The light will turn on automatically before 30 minutes of alarm time, and slowly brighten up. The brightness will reach the max at the alarm time while the nature sound start to ring. You can touch the top touch key or press any keys to stop the alarm. If it is not turned off by hands, it will be entered into the snooze mode after 5 minutes, and the alarm ring will sound again after 5 minutes. You can touch the top touch key or press any keys to stop the alarm at any time after the alarm ring.

alarm ring. If you choose the option 7 only light wake up mode and no alarm ring, when the alarm time is up, if without close the light by tap the top touch board, the light will be auto turned off after 15 minutes.

Sleep Lamp Use

Click the timer sleep button " T " to activate the sleep light mode. The sleep light icon will be light up on the display. The sleep light has three timer options: 10/30/60 minutes timer. The timer will be displayed on the screen when setted, and then elick to true off and then click to turn off.

After the sleep light is turned on, the light changes from bright to dark, and gradually goes out to help you fall sleep.

Table Lamp Application

When the machine connect the power, the table lamp with the touch of your finger on the metal panel, there are 3 level light, low, middle, high bright, off.

Long touch the panel will convert between the table lamp and the colorful light, in the colorful light mode, you can touch and switch the color of the lantern and the streamer gradient color, and then touch to turn off the light.

Safety Instructions

- Before connecting this product to the power supply, please check whether the voltage marked by the power adapter matches the local supply voltage.
- Never use an adapter that exceeds the voltage and power marked on this product to connect the machine.
- 3. If an abnormal situation occurs during use, stop using it nediately and switch off the power
- 4. Do not allow this product to enter into the water, do not use it in a humid environment (for example: bathroom, swimming
- 5. Please do not throw or hit this product to avoid damage to the product.
- 6. Recommended to use this product within the ambient temperature range: $-10\,^\circ\!C-\!50\,^\circ\!C.$
- 7. When not using for a long time, please turn off the power.

Warranty

Thank you for purchasing this finely engineered, quality product from us.

Our utmost care and attention has gone into providing you with a product which will give you one years of care–free service. Our products are covered by warranty from defects in materials and workmanship for a period of one year. The following conditions will apply. All products returned for defects in material or workmanship shall be repaired or replaced with equal units (at our option) at no charge subject to the following provisions the following provisions.

Inspection of the unit must disclose that all defects are as

8

specified and that defective equipment has not been improperly and contrary to our instructions been altered damaged by improper line voltages or polarity, increase of fuse value other than recommended, defaced or treated in

We are not responsible for product damage caused by

Has inspection Checker:QC01