

OWNER MANUAL FOR:

Bar equipment

Please read this manual carefully, and make sure to keep this manual in the place accessible by the user at any time.

THIS APPLIANCE IS INTENDED FOR PROFESSIONAL USE.

BEFORE THE FIRST USE:

- Take the appliance and accessories out of the box. Remove the stickers, protective foil or plastic from the device.
- Place the device on a flat sstable surface and ensure the minimum of 10 cm. free space around the device. This device is not suitable for installation in a cabinet or for outside use.
- Connect the power cable tot the socket. (Note. Make sure the indicated voltage on the device matches the local voltage before connecting the device. Voltage 220V 240V 50-60Hz or 380V 400V 50-60Hz.

CLEANING AND MAINTENANCE

- Before cleaning, unplug the appliance and wait for the appliance to cool down.
- Use a soft damp cloth to clean the housing of the device.
- Clean the appliance with a damp cloth. Never use harsh and abrasive cleaners, scouring pad or steel wool, which damages the device.
- Never submerge the appliance in water or other liquids.
- The device should be regularly decalcified. Use a descaling product which is suitable for household appliances.

SAFETY INSTRUCTIONS

- By ignoring the safety instructions the manufacturer cannot be held responsible for the damage.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Never move the appliance by pulling the cord and make sure the cord cannot become entangled.
- The appliance must be placed on a stable, level surface.
- The user must nog leave the device unattended while it is connected to supply.
- This appliance is only to be used for household purposes and only for the purpose it is made for.
- This appliance can be used by persons aged from 18 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- To protect yourself against an electric shock, do not immerse the cord, plug or appliance in the water or any other liquid.
- This appliance is intended to be used in household and similar applications such as:
- staff kitchen areas in shops, offices and other working environments.
- By clients in hotels, motels and other residential type environments.
- Bed and breakfast type environments.
- Farm houses
- Children shall not play with the appliance.

TROUBLESHOOTING

In case of malfunctions, please contact the dealer from whom you purchased the device.

DISPOSAL:

This product must not be disposed of with household waste. Instead, it must be taken to a collection point for the recycling of electrical and electronic equipment.

MANUFACTURER & IMPORTER:

The device complies with current EU standards and directives. If necessary, we will send you the corresponding declaration of conformity.

Imported by:

HCB B.V. - Irislaan 7, 5595EH Leende, The Netherlands

Caution: Dismantling the unit by non-professional staff is prohibited, it will cause hazard.

