

"INSTRUCTION MANUAL"



Cortin FL Tripod Teak Brown with Antique Brass
96520

Assembly Instructions
Instrucciones De Asamblea
Instructions d'Assemblée

PARTS



A




B

For indoor use only. Keep out of the reach of children and animals. Place on flat surface and away from flammable materials. Never operate this appliance if it has a damaged cord, plug or cable. Keep cord away from heated and/or damp areas.

CAUTION! Only use Type A 40 Watt bulb or CFL equivalent

1

Place Lamp in room and adjust left to right.
Tighten screw firmly. See inset below.



QAZQA

WWW.QAZQA.COM