


Wooden picnic table Jumbo 300 cm










opposite side

- Tighten the screws at the end of the construction and check them regularly afterwards
- Do not use power screw drivers as they might cause splitting
- Only use special cleanser or impregnate oil to clean wooden products and water and soap for aluminium and steel products
- Use soft brushes when cleaning to avoid scretching the surface
- Protect your furniture/products with a cover when you are not using it

STAP 3 Bevestig 6x poottafel G aan tafelblad K


de lange hankjes (E).

met 12 x slotbout form. 12 x ring on 12 x dopinder volgens tekening. Plaats de ooten in een rechte ign togonover elkaar volgons tekening,



Wooden picnic table Jumbo 300 cm





Care instructions

- Tighten the screws at the end of the construction and check them regularly afterwards
- Do not use power screw drivers as they might cause splitting
- Only use special cleanser or impregnate oil to clean wooden products and water and soap for aluminium and steel products
- Use soft brushes when cleaning to avoid scretching the surface
- Protect your furniture/products with a cover when you are not using it