

## Instructions

Two competent adults are required to assemble this product.

1. It is recommended to test the product to ensure it is fully working. Add 0.5lt - 1lt of water to the acrylic tube by removing the lid and gently pouring water directly into the top of the Tube. Plug the adapter in and turn the item on, ensuring the lights and remote is working, ensuring the pump is heard. You should see a small amount of bubbles occurring in the bottom of the panel. Now empty the water again by pouring out into a bowl, sink, bath or outside.
2. Decide where you wish to place this product and stand in position.
3. Once in position gently fill the acrylic tube with water until the water level is approximately 1/2" from the rim.
4. Add the beads to the bubble tube
5. Plug the adapter in the black jack/socket at the base and plug the other end into the wall socket.
6. Using your remote to control the lights and mode

## Remote Control Functions

Increase/decrease  
brightness on static  
colour mode

Play/pause any  
dynamic colour  
changing pattern



Turn on/off

Selections of colour  
in static mode

Cycles through all  
colours randomly  
(speed can be adjusted)

Turns ON/OFF static  
colour in strobe mode  
(speed can be adjusted)

Increase/decrease  
speed on all dynamic  
modes

Trio or Seven colour instance  
change (speed can be adjusted)

Trio or Seven colour fade  
(speed can be adjusted)

To change the battery in the remote, please follow the instructions on the reverse of the remote.