INTEX[®] OWNER'S MANUAL Quick-Fill[™] Electric Air Pump

Model AP640; 220 - 240 Volt ~ 50 Hz; 100 W


READ AND FOLLOW ALL INSTRUCTIONS BEFORE USING THIS PRODUCT

ARNING

- Adult use only.
- Do not drop unit into water or expose unit to rain or water.
- Do not direct air stream at face or body.
- Do not operate for more than 10 minutes at a time. Unplug and let cool at least 10 minutes.
- Unplug unit when not in use.
- Do not obstruct vent holes or open source.
- Do not insert objects into the inflation or deflation connector.
- . The AC supply cord cannot be replaced. If the cord is damaged the appliance should be scrapped.
- To reduce the risk of electric shock, do not expose to rain. Store indoors.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

FOLLOW THESE RULES AND ALL INSTRUCTIONS TO AVOID PROPERTY DAMAGE. ELECTRIC SHOCK, BURNS OR OTHER INJURY.

NAMES OF PARTS



NOTE: Drawings for illustration purpose only. May not reflect actual product. Not to scale

INSTRUCTIONS

Genera

- · Return pump and nozzles to package when not in use.
- · No specific air pump maintenance is required.

SAVE THESE INSTRUCTIONS

Page 1

203-***-R0-2005

CAUTION

In order to avoid a hazard due to inadvertent resetting of the thermal cut-out, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.

INSTRUCTIONS

INFLATION

1. Attach nozzle to the inflation connector if necessary and hold pump against inflation valve on item to be inflated. See Fig (1).

NOTE: On large items like inflatable boats and large air mattresses, the pump will fit directly into the inflation valves and provide faster inflation times. Use the appropriate nozzle on small inflation valves as on small air mattresses, etc.

- 2. Plug in the AC line cord into an AC electrical outlet. See Fig (2).
 - FIG (1): ATTACH NOZZLE 110-120\ 220-240V FIG (3): SWITCH FIG (2)

DEFLATION

INTEX[®]

1. Attach nozzle to the deflation connector if necessary and hold pump against inflation valve on item to be deflated. See Fig (4).

NOTE: On large items like inflatable boats and large air mattresses, the pump will fit directly into the inflation valves and provide faster deflation times. Use the appropriate nozzle on small inflation valves as on small air mattresses, etc

- Plug in the AC line cord into an AC electrical outlet. See Fig (2).
- 3. SWITCH ON: Press "I"; SWITCH OFF: Press "0". See Fig (3)




FIG (4): ATTACH NOZZLE

©2019 Intex Marketing Ltd. - Intex Development Co. Ltd. - Intex Recreation Corp. All rights reserved/Tous droits réservés/Todos los derechos reservados/Alle Rechte vorbehalten. Printed in China/Imprimé en Chine/Impreso en China/Gedruckt in China. @¹⁰ Trademarks used in some countries of the word under licens from ¹⁰ ¹⁰ Marques utilisés dans certains pays sous licence de/Marcas registradas utilizadas en algunos paises del mundo bajo licencia de/Warerzeichen verwendel in einigen Ländern der Welt ni Lzenz von/Intex Marketing Ltd. Lor) a/atan Intex Development Co. Ltd., G.P.O Box 28282, Hong Korng & Intex Recreation Corp., P.O. Box 1440, Long Beach, CA 930801 - Distributed Trading B.V., Venneveld 9, 4705 RR Roosendaal – The Netherlands www.intexcorp.com

SAVE THESE INSTRUCTIONS



203

3. SWITCH ON: Press "I"; SWITCH OFF: Press "0". See Fig (3)