



KIDS SCOOTER

WITH LED WHEELS

RDD KIDSST02

PRODUCT SPECIFICATIONS

PRODUCT NAME:
KIDS SCOOTER

PRODUCT CODE: RDD KIDSST02BU BLUE
RDD KIDSST02PK PINK

EANCODE 8718657553054
EANCODE 8718657553061

SPECIFICATIONS

Age:	3+
Weight limit:	80 kg
Handlebar height:	adjustable 66-89 cm
Bearings:	ABEC-7
Wheels:	118 mm LED
Foldable:	No

PACKAGE CONTENT

Kids scooter
Manual

RiDD & RiDE

Congratulations! You're the proud owner of a RiDD Kids Scooter. Before you hit the road for the unique driving experience offered by your new Kids Scooter, please read the attached instructions carefully.

The RiDD Kids Scooter will let you experience a new fun way of movement, so enjoy your RiDD & Ride! From now on you're part of the RiDD community, don't forget to share your experience with your RiDD with friends, family and on social media!

ASSEMBLY OF THE RIDD KIDS SCOOTER

Press the push button (F). Insert the T-bar into the scooter hole (H) as shown in figure 1. Until you hear a “click” sound to make sure the handlebars (I) are firmly in the scooter housing.

Pull down the mounting sleeve to strengthen the stability of the handlebar and the scooter body.



ADJUST T-BAR

Adjust the T-Bar according to the height of the child. Tighten the collar clamp to secure the T-bar after adjustment, as shown in picture 3 and 4.

EXTRA CHECK

Check at regular intervals that all screws are tight and the wheels are in good condition, if they are worn out, please replace them. Clean the RiDD Scooter with a soft cloth every time when you have finished using it.



WARRANTY

WARRANTY RESTRICTION

The RiDD Scooter is supplied with a warranty of 12 months for material and workmanship faults. During this period of warranty it is up to your dealer to decide whether the product is covered by the warranty and should be repaired or replaced. The warranty does not cover damage caused by improper use such as incorrect installations on the model, careless use such as running against curbs, etc. or normal weather.

WARRANTY

We can only accept warranty claims if you can hand us your receipt (copy). Keep your receipt in a safe place. If you make a claim under the warranty, your dealer will decide whether the Kids Scooter will be repaired or replaced with a new model.

- Retailer's name
- Original date of purchase
- SKU number of your RiDD product purchased
- Failure to supply a bill of sale with all of the required information will result in denial of warranty repair or replacement.

We assume that you will handle your RiDD Kids Scooter in a responsible and safe manner. The use of the RiDD Kids Scooter is entirely at your own risk. To minimize the risk of injury, you must read and follow all instructions, warnings and safety precautions carefully in this user manual, so that you will be able to use the RiDD Kids Scooter safely. The legal representative of RiDD cannot be held responsible for any physical injury and wounds to you or others. You should therefore protect yourself well by wearing high-quality protective clothing while using the product, such as a safety helmet, knee and elbow pads, gloves and sturdy shoes. The protection will absorb a large part of the impact should you fall.

SAFETY PRECAUTIONS

WARNING – FAILURE TO COMPLY WITH SAFETY INSTRUCTIONS/ INAPPROPRIATE USE OF UNIT MAY LEAD TO PROPERTY DAMAGE, BODILY HARM AND IN EXTREME CIRCUMSTANCES, DEATH.

1. Before you allow your child to use the RiDD Kids Scooter, ensure that the steering rod is fully engaged and that all the screws are tight. Also ensure that the wheels have been correctly secured and that they show no signs of friction. Adult assembly is required, or proper assembly must be checked by an adult before use.
2. Warning: protective equipment should be worn. Ensure that your child always wear a helmet and wrist-, elbow- and kneepads. Shoes with rubber soles are also required.
3. Ensure that your child does not ride down any hills. The brake is not designed to decelerate from high downhill speeds.
4. The brake pad becomes hot when it is used. Make sure that your child does not keep the brake on for a long period of time. Explain to your child that direct skin contact may cause burns.
5. Do not allow your child to travel at speeds above 5 km/h.
6. Ensure that your child does not ride on roads, paths or other places with motor vehicle traffic.
7. Always observe traffic regulations and laws. The RiDD Kids Scooter may not be used on public roads.
8. Only one child may ride on the RiDD Kids Scooter, it is not designed for more children at the same time.
9. Never allow your child to ride the RiDD Kids Scooter at dusk or at night because it has no lights.
10. The RiDD Kids Scooter must not be used on wet, oily, sandy, dirty, icy, rough or uneven surfaces.
11. Never use the RiDD Kids Scooter in wet conditions.
12. Your child should practice first to gain control of the vehicle. Ensure that your child does not attempt any experiments or risky manoeuvres with it. Riding style should always be adjusted to the personal skill of the rider.
13. Do not make any modifications to the RiDD Kids Scooter. If you do, the guarantee is expired.
14. Load capacity is up to 80 kg body weight.
15. Important: undoing the axle screws several times will reduce the effect of the screw securing product. This means that the screws may come loose by themselves. Therefore, you should always use a conventional screw securing product.

WARNINGS

WARNINGS

1. Only use the RiDD Kids Scooter with the steering rod fully engaged.
2. Always make sure that your child wears a safety-approved helmet to ride the RiDD Kids Scooter.
3. Falling off the RiDD Kids Scooter without safety precautions may cause serious or even fatal accidents. Warning: Protective equipment should be worn.
4. In wet condition there is a major risk of slipping.
Do not use the RiDD Kids Scooter in these circumstances.
5. Riding at dusk, at night or in poor visibility is very dangerous and increases the risk of accidents and injury.
6. Ensure that your child always wears safety equipment. In addition to the recommended safety equipment, your child could wear bright, reflective clothing.
7. Caution - the brake pad becomes hot after using.



RIDD HELPDISK AND SERVICE & REPAIR CENTRE



International e-mail support: support@ridd.eu

Please note: our service & repair centre will approve the warranty claimed, after receipt of the product. This judgement will be substantiated with arguments and supported by visuals. In the event the warranty term is expired or when damage is self-inflicted our service centre can also arrange a paid repair.

IMPORTANT

RiDD is distributed by Pirox International B.V. / Blaak 6 / 3011 TA Rotterdam / The Netherlands



**Kids Scooter
RDD KIDSST02**



**Foldable Kids Scooter
RDD FOLDST03**



**Foldable Scooter
RDD AFOLDST05BL**



**Stunt Scooter
RDD ST010**



**Xtreme Stunt Scooter
RDD XTRST04**

AGE	3+	5+	8+	8+	8+
WEIGHT LIMIT	80 KG	50 KG	100 KG	100 KG	100 KG
HANDLEBAR HEIGHT	ADJUSTABLE 66 - 89 CM	ADJUSTABLE 77 - 100 CM	ADJUSTABLE 77 - 100 CM	82 CM	82 CM
BEARINGS WHEELS	ABEC-7 118 MM LED	ABEC-7 125 MM	ABEC-9 200 MM	ABEC-7 100 MM	ABEC-9 110 MM
FOLDABLE	NO	YES	YES	NO	NO

