


FOLDABLE PANEL HEATER USER MANUAL

THANKS FOR PURCHASING OUR PRODUCTS, PLEASE READ THE USER MANUAL BEFORE USE

ITEM NO:LY-PH4



PRODUCTS PARAMETER

Size: 100*51cm

Item No.: LY-PH4

Input: 230V/AC/50

Rating power: 165 W

Safety device:

- * In case product fall down, when the angle to floor less than 45° , the products will stop working
- * Timer: 3 hours

HOW TO USE

Turn on/off

Plug it to outlet power, press power button to turn on at H temperature, power LED will light.

Press power button again to turn off, power LED will off

Setting temperature

Press UP or DOWN button to select H, M or L

LED indicator instruction:

Connect the products with AC power, all LED will light for 2 seconds, then off.

Press power button, power LED and H LED will on

Press UP or DOWN to setting temperature, LED for H, M or L will indicate present setting.

NOTICE

Danger:

- * Don't prick the products by metal or any conductive materials.
- * Don't cover the products by clothes, towel or blanket for long time during in use.

Warning

- * Please read the instruction sheet carefully before use.
- * Don't prick the products by sharp object.
- * Don't clean the product with corrosive cleaning agent or diluent.
- * Dependent people, infant or The temperature insensitive people must be accompanied by a guardian during using.
- * Far away from fire. Don't use it with other heating device.
- * Keep far away from pet
- * Turn off power when the surface got wet. Use it after complete dry.
- * Don't pull or twine the power cord.
- * Turn off the controller and disconnect the power when no use.
- * Keep it at shady and dry place for storage.



Read the instruction before use



Don't pinprick



No cover




Keep away from pet.



Don't soak




No dryer



No Chlorine Bleach



Don't dry cleaning



Iron temperature less than 100°C




Natural drying

INSTRUCTION


A - heat side (face to the controller)

B - no heat side (back of the controller)


C - Stand the pad in the arrow direction



Correct



will not work if stand in wrong direction



will stop working if angle to floor less than 45°

