

A large, light gray, stylized number '2' is positioned in the background, spanning most of the page. The top curve of the '2' is at the top right, and the vertical stem is on the left side.

tricycle assembly manual

Nederlands | English

#myveloretti

Veloretti Brandstore
Van Woustraat 72
1073LN Amsterdam
The Netherlands

Veloretti Headquarters
Helicopterstraat 25B
1059CE Amsterdam
The Netherlands

info@veloretti.com
+31 (0)20 26 11 433

Tricycle Set

Introductie

Met deze driewieler set is je Veloretti Mini helemaal compleet. Deze uitbreiding voorziet de jouw kleine superheld van balans en leert hen op een veilige en leuke manier fietsen.

Stap 1

De Veloretti Tricycle Set bevat naast een wiel; drie afstandhouders van verschillende formaten, een lange as, vier zwarte adaptors en twee moeren.

Stap 2

Plaats de korte afstandhouder aan de achterkant van het frame. Steek de lange as door het frame en de afstandhouder. Plaats aan de linker- en rechterzijde de overige afstandhouders.

Stap 3

Neem het wiel en installeer aan beide kanten van het wiel de zwarte adaptors. Plaats de wielen aan de linker- en rechterzijde van de as.

Stap 4

Plaats op beide uiteinden van de as de moeren en draai deze stevig aan met de meegeleverde inbussleutels.

Verantwoordelijkheid ouders

De Veloretti Mini voldoet aan de eisen van de Europese Richtlijn Speelgoed, zoals aangegeven door het CE-keurmerk. Wanneer de fiets tijdens het spelen conform de voorschriften wordt gebruikt, is het veilig voor gebruik. Let er echter op dat door de natuurlijke behoefte aan beweging en het enthousiasme van kinderen onvoorspelbare situaties kunnen ontstaan die de aansprakelijkheid van de fabrikant uitsluiten. Instrueer kinderen daarom in het juiste gebruik van de loopfiets. Houd toezicht en maak hen attent op mogelijke gevaren.

Waarschuwing

Beschermende uitrusting dient te worden gedragen. Veloretti adviseert het dragen van een fietshelm en dichte schoenen. De toegelaten totale belasting van het frame bedraagt 30 kg.

Gebruik


De fiets dient alleen op geschikte speelterreinen en veilige omgevingen gebruikt te worden. Gebruik de fiets niet in gebieden die potentieel gevaarlijk zijn. Dit kunnen gebieden zijn met auto's, vijvers, open water, bruggen, trappen, hellingen etc. De fiets voldoet niet aan de eisen van het verkeersreglement en mag niet gebruikt worden in het reguliere wegverkeer. Gebruik de fiets alleen onder toezicht van een volwassene.

Aansprakelijkheid


Veloretti BV is niet aansprakelijk voor verwondingen en/of incidenten die ontstaan door het gebruik van de fiets. De koper aanvaardt het risico van activiteiten die met de fiets worden beoefend. Bewaar deze handleiding en veiligheidsvoorschriften voor toekomstig gebruik. De fiets mag alleen worden gemonteerd door een volwassene.

1


3 afstandshouders 

1 lange as 


4 zwarte adaptors 

2 moeren 


3



2



4



Tricycle Set

Introduction

With this Tricycle set your Veloretti Mini is everything it should be. This add-on gives the bike stability for your little one. Teach your child to balance and cycle in a safe and fun way.

Step 1

This Veloretti Tricycle Set contains apart from the wheel; three spacers in different lengths, a long axle, four black adaptors and two axle nuts.

Step 2

Insert the alloy middle spacer in the rear-end of the frame. Install the long axle through the frame and middle spacer. Finally, put on both sides of the axle the side spacers.

Step 3

Put the black adaptors on both sides of the wheel.

Step 4

Install both wheels on the axle and mount both axle nuts. Tighten it counterclockwise and make sure to use the supplied Allen keys to tighten it properly.

Parents' responsibility

The Veloretti Tricycle Set meets the requirements of the European Toy Safety Directive, as identified by the CE-mark. When playing in accordance with the instructions, there is hardly any risk with using the bike. However, due to children's enthusiasm and natural need for movement, unpredictable situations may occur, for which the manufacturer cannot be held responsible. Therefore, it is important that children are instructed on how to use the balance bike correctly. It is the parents' responsibility to supervise their children whilst playing.

Warning

Protective equipment should be worn. Veloretti advises the use of a bicycle helmet and closed shoes. The bike is not to be used in traffic. Maximum permissible load is 30 kg.

Usage

Please only use this bike on suitable playgrounds or safe areas. Do not use the bicycle in areas that are potentially dangerous. These can be areas with cars, ponds, open water, bridges, stairs, slopes, etc. The bike doesn't comply with the requirements of the highway code and must not be used in traffic. Make sure that your child uses the bike with caution since skill is required to avoid falls or collisions. Only use the bicycle under adult supervision.

Liability


Veloretti BV is not liable for injuries and/or incidents that arise from the use of the bicycle. The buyer accepts the risk of activities that are practiced by bicycle. Save this manual and safety instructions for future use. The bicycle may only be mounted by an adult.

1

3 spacers



1 long axle




4 black adaptors




2 axle nuts




3



2



4



VELORETTI