





# Déko-Play schommelzitjes gebruiksaanwijzing




Voor een speeltoestel met een balkhoogte van 2,5m.



150100




150601




150684  
     
 150681 150682 150683



150150





150312  
   
 150314





RVS ketting

150216





150210

- 150322 met inlegkussen
- 150324 met inlegkussen
- 150331 met inlegkussen en met verstelbare touwen
- 150334 met inlegkussen en met verstelbare touwen





RVS beslag

150215



150903  
     
 150901 150902 150904



150802  
   
 150801



150671  
   
 150674

