




DIGITAL COUNTING moneybox

- LCD screen
- permanent memory function
- automatic accumulation
- reset button
- set, minus (-) and plus (+) buttons
- 2 master keys included to un-lock moneybox

requires 2 x AAA batteries
(not included)



Also available in
green and gold



Warning!
Not suitable for
children under
3 years.

Small parts-Choking hazard