

**OPERATION GUIDE**

To twist the lock of the battery cover, please see the picture on the right. Insert 1.5V "AA" batteries into the car according to its polarity, then close the battery cover.  
 Insert 1.5V "AA" batteries into the controller according to its polarity, then close the battery cover.  
 Turn the car, so it can be operated.  
 To control the car running in a straight line.



**CAUTION**

Used batteries are not to be mixed. Exhausted batteries are to be removed immediately. Batteries are to be inserted with the correct polarity. The supply to be recharged. Rechargeable batteries are to be removed from the toy charged under adult supervision. Leaked or damaged batteries are not to be used.


ent type are recommended to be used.  
 Any source of heat, water or direct sunlight.  
 Immediately if you make contact with leaked liquid from the battery.  
 Rechargeable batteries, please regularly recharge them. Only a charger of the same or type used.  
 Do not dispose of in fire.  
 It may trigger epilepsy in sensitised individuals.

Mercedes-Benz and are the intellectual property of Mercedes-Benz Group AG. They are used by Mercedes-Benz Group AG under license.  
 RASTAR (HK) INDUSTRIAL COMPANY LIMITED  
 RASTAR GROUP  
 Industrial Park, Xiadao Road, Shanghai, China.  
 Shantou, Guangdong, China.  
 rastar.com  
 CHINA

The packaging has to be kept since it contains important information.  
 Specifications, colours and contents may vary from illustration.



6 930751 304147



ITEM NO.40100

**WARNING:**  
 CHOKING HAZARD-Small parts.  
 Not for children under 3 years.

تحذير:  
 خطر الاختناق - أجزاء صغيرة  
 غير مناسبة للأطفال تحت 3 سنوات



20230810

Full Function Radio Control: Forward, Reverse, Turn Left, Turn Right

